



- = 1000V - Betriebsspannung  
 □ = 500V - " "  
 ▢ = 350V - " "  
 ▣ = 250V - " "  
 ▤ = 165V - " "  
 ▥ = 12V - " "  
 ▦ = 10V - " "

- ⊕ = 1/4 W Belastbarkeit  
 ⊖ = 1/2 W " "  
 ⊞ = 1 W " "

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
KW 1																								
KW 2																								
MW																								
LW																								
TA																								

