


# BIENNOPHONE 8052

		Komponentenliste - Component List																											
Pos.	Bezeichnung	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
1	Antenne																												
2	Netz																												
3	Lampe																												
4	Netzschalter																												
5	Netzstecker																												

© Schaffner grossbause



Sport SA Bienne