


PHILCO Tuner-Amplifier Chassis P10ST used in Models P1002 and P1718

(Diagram continued on page at right; other material on page following)



PHILCO Tuner-Amplifier Chassis P10ST used in Models P1002 and P1718

CHASSIS REMOVAL - P10ST, P25ST,

3. Remove holddown screws at rear of chassis.
4. Remove screws inside of cabinet at corners of front bezel.
5. Remove screws holding EXT. SPKR. JACK PLATE to cabinet.
6. Remove chassis from front of cabinet; in drop-in models lift lid then lift chassis up and out of cabinet.

