



EM11

**(2. Teil des Schaltbildes)**



Wellenbereich	Antennenvorkreis		Oszillator		Zwischenkreis	
	L	C	L	C	C	L
L 160 kHz 263 kHz	L8	C5	L29	C12	C71	L18
M2 556 kHz 1088 kHz	L9	C6	L30	C21	C12	L19
M1 1088 kHz 1538 kHz	L10	C7	L31	C22	C14	L21
K2 50 m 30 m	L11	C8	L32	C23	C15	L22
K1 30 m 16 m	L12	C10	L33	C25	C17	L23
U 85 MHz			L20			L14