


Kaiser W 1060 Danzig  
(1. Teil des Schaltbildes)


Gez. Schaltstellungen: UKW und Musik

		Mus.	Sprach.	D	L	M	K	U
1	13							
2	14							
3	15							
4	16							
5	17							
6	18							
7	19							
8	20							
9	21							
10	22							
11	23							
12	24							


ZF = 472 kHz + 10,7 MHz




EM 35



EF41, EL41



E-80



EC 92

