



Kaiser W950 Sonate (1. Teil des Schaltbildes)




Gez. Schaltstellungen: UKW u. Musik

	Mus.	Sprach.	Q	L	M	K	U
1 13							
2 14							
3 15							
4 16							
5 17							
6 18							
7 19							
8 20							
9 21							
10 22							
11 23							
12 24							


ZF = 472 kHz + 10,7 MHz




EL11




EM35



EF41



E-80



EC92

