



## PHILCO TRANSITONE HOME RADIO MODELS PT-29 AND PT-31

Schem. No.	Description	Philco Part No.	Schem. No.	Description	Philco Part No.
1	Antenna Transformer	32-3164	18	Resistor (4.7 meg., ¼ watt)	33-547154
2	Tubular Condenser (.0015 mf., 200 v.)	30-4555S	19	Resistor (220,000 ohms, ¼ watt)	33-422154
3	Tuning Condenser	31-2427	20	Tubular Condenser (.01 mf., 400 v.)	30-4572S
4	Switch	42-1406	21	Resistor (47,000 ohms, ¼ watt)	33-447154
5	Tubular Condenser (.05 mf., 200 v.)	30-4519S	22	Resistor (130 ohms, ½ watt)	33-113336
6	Tubular Condenser (.15 mf., 400 v.)	30-4505S	23	Tubular Condenser (.04 mf., 400 v.)	30-4119S
7	Resistor (47,000 ohms, ¼ watt)	33-347154	24	Output Transformer	
8	Mica Condenser (110 mmf.)	30-1130		Part of Speaker No.	36-1469
9	Oscillator Transformer	32-3152	25	Speaker	36-1469
10	Tubular Condenser (.05 mf., 200 v.)	30-4519S	26	Electrolytic Condenser (20-20 mf., 150 v.)	30-2382
11	1st I. F. Transformer	32-3149	27	Field Coil Part of Speaker, Part Number	36-1469
12	2nd I. F. Transformer	32-3150	28	Pilot Lamp	34-2068
13	Resistor (2.2 meg., ¼ watt)	33-522154	29	Line Resistor	33-3367
14	Mica Condenser (250 mmf.)	61-0033	30	Tubular Condenser (.04 mf., 400 v.)	30-4119S
15	Resistor (22,000 ohms, ½ watt)	33-322334			
16	Volume Control (500,000 ohms)	33-5306			
17	Tubular Condenser (.01 mf., 200 v.)	30-4479S			