


# Emerson Radio

MODELS:  
31T09, 31T10, 31T11  
31L09, 31L10, 31L11

Chassis 120791, 120792, 120793, 120794. Similar Chassis 120826, 120828, are also used in some of these models.



31L11

## SERVICING PRECAUTIONS

- 1) Do not operate the chassis without a loudspeaker or suitable dummy load connected to the secondary of the audio output transformer, since this may result in damage to the audio output transistors.
- 2) Note that B - (chassis ground) is connected to one side of the power line through R-11. For this reason, an isolation transformer must be used whenever servicing procedures require that a signal be conductively (by direct connection) injected into the receiver, otherwise damage to the chassis may result.

