



Service
Service
Service



Service Manual



MISC	S1	TS1	S3	D1	S2	TS2	S4	D3	S5	D2	S6	D8	TS3	S7	S11	TS4	D4	S12	S8	S13	TS5	S9	D7	S10	D5	D6	TS6	TS7	TS8	D9	TS9	TS10	TS11	S21	MISC																			
C	2	VC1a	CTa	1	3	4	5	9	6	7	8	11	CTb	VC1b	10	25	26	27	30	31	33	36	32	38	40	39	41	42	44	46	45	62	43	49	47	48	59	61	60	63	64	65	66	67	70	69	71	72	76	79	61	C		
C	VC1c	73	13	CTc	15	12	14	16	3	4	5	VC1d	CTd	80	20	75	22	74	24	17	19	21	23	11	14	15	18	19	20	23	24	26	25	27	34	33	29	30	68	31	32	40	38	39	41	42	43	49	51	55	58	56	61	C
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																				R		
R																																																						




MISC	TS5																											S12,13,8	D4	S11	D8	S15	TS4	TS6			S1	S7	D10,11	CT d	CTc	TS3	D2	S6,17	S5	SK-A			MISC										
MISC	D15VL1D13,14,16,7																											S9,14,10	TS13	D5,6,12	S16	TS12,10			TS1,11,9			S2	D9	CTa	D1	CTb	S4	S3	TS8	TS2,7			D3	MISC									
C	39																											38	65	37	42	36	43	33	32	44	64	17			74	69	63	30	31	16	73	27	13	14	12	21	15	C					
C	41																											49	40	45	35	34	47	48	21	18	23	20	75	19	80	24	22	1	2	3	4	5	11	8	10	9	7	6	25	26	28	29	C
C	78																											72	76	77	71	70	79	46	67	50	66	61			60	59	58	68	54	52	51			53	56	55			57	C			
R	59																											20	25	24	68			22	46	28	19	40			15			18	69	6	7	14	11	67				R					
R	33																											26	27	37	23			37	36	21	29	31	8			10	12	9	1			2	16			3	5	4	17	39	38	R	
R	66																											34	33	62			64	63	55	56	61	60	47	49	58	57	54	51			53	50	48	65	44	41	43	42	13	45	R		



74010

CS54237

Wave range	Signal to		Var.cap.	Detune	Adjust	Indication
SK-A						
MW (520-1605 kHz)	<div>1</div> via 39 nF	<div>A</div>	Min.cap.	S11,S12 S13,S14	S14	<div>1</div> max.
					S13	
					S12	
					S11	
	512 kHz	<div>B</div>	Max.cap.		S16	
1635 kHz	Min.cap.		CTd			
600 kHz	Tune in		S18			
1400 kHz			CTc			
LW (150-255 kHz)	147 kHz	<div>B</div>	Max.cap.		C24	<div>1</div> max.
	200 kHz		Tune in	S19		
SW (5.95-15.45 MHz)	5.8 MHz	<div>C</div> via 5 pF	Max.cap.		S15	<div>1</div> max. <div>2</div>
	15.9 MHz		Min.cap.		C19	
	6.5 MHz		Tune in		S17	
	14.5 MHz				C13	
FM (87.5-104 MHz)	10.7 MHz via 22 nF $\Delta f =$ 200 kHz (50 Hz)	<div>D</div>	Min.cap.	S5,S6 S7,S8 S9,S10	S9	<div>2</div> <div>3</div>
					S8	
					S7	
					S6	
					S5	
		<div>E</div> via 39 pF			S10	<div>3</div> <div>4</div>
	87,5 MHz		Max.cap.		S4	<div>3</div> max.
	104 MHz		Min.cap.		CTb	
	88 MHz		Tune in		S2	
	102 MHz				CTa	
<div>Repeat - Herhalen - Répéter - Wiederholen - Repetera - Ricominciare - Repetera - Gentage - Gjentaglse - Toisa</div>						



7398A