MOTOROLA, INC. Circuit diagrams of Models 5R11AU, 5R12AU, 5R13AU, 5R14AU, 5R15AU, 5R16AU, all using Chassis HS-281, are shown on this page. Chassis HS-280, used in the same numbered models but with a suffix "A" (not "AU"), omits choke-capacitor E1 and connects one side of the line to chassis. Chassis HS-242 and HS-254, used in the same numbered models but without any suffix or with suffix "U" only, use 35W4 rectifier.