
ANTENNA
GROUND
BLACK
RED
DET. OSC.
TUNING COND.
1C6
1st I. F.
34
2d DET.
30
1st AUDIO
32
DRIVER
30
OUTPUT
19
OUTPUT TRANSFORMER (on Speaker)
SPEAKER
VOICE COIL
PILOT LAMP
1st I.F. TRANS.
2nd I.F. TRANS.
VOLUME CONTROL
TONE CONTROL
AUDIO TRANSFORMER
ANTENNA TRANSFORMER
OSCILLATOR TRANSFORMER
WAVE TRAP
RED TAP LINE
POLICE TAP
STD B.C. SERIES
STD B.C. ST
SW SERIES
SW BAND SWITCH
ON-OFF SWITCH
+135 V.
+67.5 V.
+2.0 V.
-B,+C.
-A.
-C, 3.0 V.
-C, 7.5 V.
I.F. 460 KC.
Philco Radio
MODEL 623
(Battery Operated)
Numbers Indicate Relative Positions of Switch Sections as Seen from Front of Chassis
All Switch Sections Shown in Position No. 3
YELLOW
YELLOW BLACK TR.
BLACK
GREEN
BLUE
Terminals on Battery Cable Plug