

RCA Models 516, 517

Precautionary Lead Dress.—

1. Dress the power cable to switch on the volume control close to the chassis and away from all grid and diode leads and condensers.
2. Dress capacitors in the 12SQ7 grid circuit away from all wiring.
3. Green and black phono wires should be twisted and dressed away from other parts and leads.
4. 50L6-GT filament wires should be dressed to rear of chassis and away from the second I-F transformer leads.
5. Dress brown lead from second I-F transformer to 12SQ7 away from power cable.
6. Dress wire to No. 1 grid of the 12SA7 away from pilot lamp leads.
7. Dress wire from loop to variable condenser away from chassis.
8. Dress all capacitors, leads, etc. which come close to oscillator coil rigidly and as far as possible from it.