


Service Manual



ORDER NO.
ARP2018

STEREO CASSETTE DECK

CT-959

CT-959 HAS FOLLOWING VERSIONS:

Type	Power requirement	Export destination
HEM	AC220V, 240V (switchable) *	European continent
HB	AC220V, 240V (switchable) *	United Kingdom

* Change the primary wiring of the power transformer.

- This manual is applicable to the HEM and HB types.
- Ce manuel pour le service comprend les explications de réglage en français.
- Este manual de servicio trata del método a juste escrito en español.

CONTENTS

1.	EXPLODED VIEWS AND PARTS LIST.....	2
2.	PACKING.....	9
3.	SCHEMATIC DIAGRAM.....	10
4.	BLOCK DIAGRAM.....	16
5.	P.C. BOARDS CONNECTION DIAGRAM.....	17
6.	P.C.B's PARTS LIST	25
7.	ADJUSTMENTS	30
7.	RÉGLAGES.....	35
7.	AJUSTES	40
8.	FOR HB TYPE.....	45
9.	PANEL FACILITIES	46
10.	SPECIFICATIONS	49

1. EXPLODED VIEWS AND PARTS LIST

NOTES :

- Parts without part number cannot be supplied.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊗" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

1.1 Parts List of Exterior

Mark	No.	Part No.	Description	Mark	No.	Part No.	Description
Δ	1	CM-22B	Strain relife		46	IBZ40P080FCC	Screw
Δ	2	ADG1036	AC power cord		47	RBN-006	Jack nut
Δ	3	REK-098	FU701, FU702 Fuse (630MA)		48	REC-371	Binder
	4	RTT1132	Power transformer (T1)		49	RXX1064	Cassette plate assembly
Δ	5	SLF-401C	LED (D3)		50	RXX1279	Bonnet
	6	PNB1109	Absorber plate (B)		51	RXX1281	Front panel assembly
	7	RBF1019	Washer		52	RLP1026	Door lens
	8	RBH1144	Button spring		53	BBT30P080FCU	Screw
	9	RBH1222	Door spring (L)		54	BBZ30P080FZK	Screw
	10	RBH1223	Door spring (R)		55	PMA30P060FCU	Screw
	11	RBL-059	Cassette plate spring		56	IBZ30P150FCC	Screw
	12	REB1038	Stabilizer (B)		57	REB1117	Door cushion
Δ	13	REK-103	FU703, FU704 Fuse (2A)		58	BPZ40P100FZK	Screw
	14			59	WA30W120R100	Washer
	15	RNH-184	Cord clasper		101		Main unit
	16	ABE1009	Washer		102		Headphone unit
	17	VXA1257	Insulator assembly		103		Power switch unit
	18	FBT40P080FZK	Screw		104		Operation unit
	19			105		Control unit
	20			106		Timer unit
	21	RAA1009	Counter reset knob		107		INPUT VR unit
	22	RAC1410	Power button		108		Pin jack unit
	23	RAC1411	Function knob		109		Rubber spacer (A)
	24	RAC1412	Slide SW knob		110		Rubber spacer
	25	RAC1413	Push knob		111		Transformer sheet
	26	RAC1414	Knob (B)		112		Mechanism sheet
	27	RAC1415	Mode knob		113		Mechanism sheet (2)
	28	RAH1542	filter		114		VR shaft
	29	REB1094	Side rubber		115		Main chassis
	30	REB1119	Door sheet		116		Center stay
	31			117		P.C.B base
	32			118		Binder
	33	RNK1366	Line straight lens		119		VR holder
	34	RNK1495	Door		120		FL shield plate
	35	RXA1281	VR knob assembly (A)		121		Joint
	36	RAH1661	Door panel		122		VR shaft guide
	37	RLP1027	FL lens		123		P.C.B stad
	38	RNA1316	Rear panel		124		Panel stay
	39	ABZ26P080FZK	Screw		125		Name plate
	40	BBT30P060FCC	Screw		126		Cassette plate
	41	BBT30P100FZK	Screw		127		Front panel
	42	BBZ30P100FZK	Screw		128		Mechanism unit
	43	BBZ40P080FZK	Screw		129	
	44	IBZ30P060FCC	Screw		130		Protector 300×10
	45	IBZ30P100FCC	Screw		131		Cushion
					132		Acetate tape 10×10
					133		PS holder
					134		Acetate tape (K)

1.1 EXTERIOR

CT-959

A

A

B


B

C

C

D

D



1

2

3

4

5


6

4

1.2 Parts List of Mechanism Section

Mark	No.	Part No.	Description	Mark	No.	Part No.	Description	Mark	No.	Part No.	Description
	1	RSX1004	Rotary encoder		56		126		Second pulley assembly
	2	RXM1016	Capstan motor assembly		57	BCZ30P060FMC	Screw		127		Cassette plate spring
	3	RXM1018	Reel motor assembly		58	BMZ26P030FZK	Screw		128		Position spring
	4	RBA1074	Step screw		59	BMZ26P040FMC	Screw		129		Plate rubber (A)
	5	RBL-044	Thrust spring		60	BMZ26P060FZK	Screw		130		Plate rubber (B)
	6	REB1099	Insulator		61	BMZ30P080FZK	Screw		131		Door arm
	7	RBL-028	Pinch spring		62	JGZ20P025FMC	Screw		132		Pocket frame
	8	RBL-030	Pinch thrust spring		63	PMA26P050FZK	Screw		133		Eject lever
	9	RBL-098	Sub-pinch spring		64	PMA26P060FZK	Screw		134		Shift shaft assembly
	10	REB-501	Capstan belt		65	PMZ20P080FZK	Screw		135		Door frame (R) assembly
	11	REB-509	Capstan belt (A)		66	RBF-030	Oil stopper		136		Door frame (L) assembly
	12	RNL-016	Tape guide		67	RBF-069	Thrust washer (A)		137		Earth lead assembly
	13	RXA1176	Flywheel assembly		68	RBF-070	Thrust washer (B)		138		REC switch unit
	14	RXA1177	Sub-flywheel assembly		69	RBF-076	Washer		139		Tape selector unit
	15	RXA1342	Metal holder assembly (A)		70	RBF1040	Oil stopper		140		Sensor unit (A)
	16	RXA1343	Metal holder assembly (B)		71	REC-371	Binder		141		Sensor unit (B)
	17	RXB-876	Pinch roller arm (R) assembly		72	REF-022	Steel ball (3mm)		142		Door switch unit
	18	RXB-877	Pinch roller arm (A) assembly		73	REF-023	Steel ball (4mm)				
	19	RBL-031	BT spring (A)		74	VCT30P060FZK	Screw				
	20	RBL-032	BT spring (B)		75	VCZ26P080FMC	Screw				
	21	RBL-033	Idler pressure spring		76	WA21D040D013	Washer				
	22	RNK-815	Reel shaft cap (B)		77	WA26N070W040	Washer				
	23	RXB-751	BT disk assembly		78	WA32D080D050	Washer				
	24	RXB-874	Reel base assembly		79	YE20FUC	E ring				
	25	RXB-875	Take-up idler assembly		80	YE25FUC	E ring				
	26	RBF-065	Washer		81	YE30FUC	E ring				
	27	RBL-037	Head base spring		82	YS24FBT	Snapring				
	28	RBL-038	Brake spring		83	RXX1055	Power motor assembly				
	29	REB-502	Drive belt		84	RXX1228	Head base assembly				
	30	REB-511	Brake shoe		101		E head				
	31	RNL-723	Brake		102		R&P head				
	32	RNL-729	Cam gear		103		Connector unit				
	33	RXB-884	Side cam gear assembly		104		Power motor				
	34	RBL-027	Pocket spring (A)		105		Insulator spring				
	35	RBL-039	Eject spring		106		Reel motor mounting plate				
	36	RBL-040	Half set arm spring		107		Flywheel holder				
	37	RBL-041	REC functioning spring		108		Motor bracket				
	38	RBL-042	Detection functioning spring		109		Thrust holder				
	39	RBL-043	Lock lever spring		110		Mechanism chassis assembly				
	40	REB-447	O ring		111		Pressure arm (R)				
	41	RNH-184	Cord clasper		112		Pressure arm (L)				
	42	RNK1498	Cassette plate		113		Adjustment nut				
	43	RNL-733	REC detector arm		114		Head base set spring				
	44	RNL-734	Chrom detector arm		115		Head adjustment spring (C)				
	45	RNL-735	Metal detector arm		116		Hight spring				
	46	RNL-739	Piston		117		Head base				
	47	RNL-740	Cylinder		118		Sub-head base				
	48	RNL-741	Lock lever		119		E head base				
	49	RNL-742	Collar		120		Brake lever				
	50	RNL-849	Pocket (L)		121		First pulley				
	51	RNL-850	Pocket (R)		122		Gear chassis assembly				
	52	RBF-057	Washer		123		Pinch base assembly				
	53	BBZ26P080FZK	Screw		124		Pinch lever assembly				
	54		125		Gear base assembly				
	55	BBZ30P080FZK	Screw								


1.2 MECHANISM UNIT






SCHEMATIC DIAGRAM

- RESISTORS :**
Indicated in Ω , $1/6W$, $\pm 5\%$ tolerance unless otherwise noted
k; k Ω , M; M Ω , (F); $\pm 1\%$, (G); $\pm 2\%$, (K); $\pm 10\%$, (M); $\pm 20\%$ tolerance.
- CAPACITORS :**
Indicated in capacity (μF) /voltage (V) unless otherwise noted
p; pF.
Indication without voltage is 50V except electrolytic capacitor.
- VOLTAGE CURRENT :**
: DC voltage (V) at play state.
mA; DC current at play state.
Value in () is DC current at stop state.
- OTHERS :**
: Signal route.
: Adjusting point.
The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
* marked capacitor and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.






A

B

C

D




A

B

C


D

4. BLOCK DIAGRAM



5. P.C. BOARDS CONNECTION DIAGRAM

• View from component side









A

B

C


D



VR552	IC551	Q510	Q741, Q753	Q512
VR551	Q552	Q512	Q754	
	Q551	IC732	Q506, Q502, Q752, Q751	Q501
	Q511	IC731		
VR502		Q505	Q504, Q503	
VR501		Q413,		
		Q411,		
VR401		Q409,		
		Q403,		
VR351		Q407,		
		Q405,	Q702, Q701	
		Q355,		
		Q401,		
		Q351,		
IC401	IC152	IC701		
	IC351	IC702		
IC301	Q352			
	Q353,			
	Q402, Q356,			
	Q406,			
	Q408,			
VR352	Q404,			
VR402	Q410,			
	Q414,			
	Q412,			
	Q603,			
	Q601,			
VR281	Q281,			
VR101	Q606,			
VR105	Q602,			
	Q604,			
	IC282,			
	IC281,			
	Q103,			
	Q101,			
VR282	IC101,	Q282,		
	Q102,	IC201,		
	Q104,			
VR106	IC251,			
VR102				

Part Number	Quantity	Description	Notes
Q510	1	Diode	
Q741, Q753	2	Diodes	
Q754	1	Diode	
Q512	1	Diode	
IC732	1	IC	
Q506, Q502, Q752, Q751	4	Diodes	
Q501	1	Diode	
IC731	1	IC	
Q505	1	Diode	
Q504, Q503	2	Diodes	
Q413, Q411, Q409, Q403, Q407, Q405, Q702, Q701, Q355, Q401, Q351	13	Diodes	
IC152, IC351, IC701, IC702	4	ICs	
IC301, Q352, Q353, Q402, Q356, Q406, Q408, Q404, Q410, Q414, Q412, Q603, Q601	20	Diodes	
Q281, Q606, Q602, Q604, IC282, IC281, Q103, Q101, IC101, Q102, Q282, IC201, Q104, IC251	17	Diodes	

1. This PCB dimension diagram is derived from the parts specified list.
 2. The parts which have been mounted on the board, can be replaced with those shown with the corresponding wiring symbols, see table above.
 3. The capacitors (shown as marked with 'C') should be replaced with the value marked on the capacitor.
 4. The diodes marked with 'D' should be replaced with the value marked on the diode.
 5. The transformer terminals marked with 'T' should be replaced with the value marked on the transformer.



A

B

C

D

15

11

10

9

8

7

15

11

10


9

8

7

5. P.C. BOARDS CONNECTION DIAGRAM

• View from soldering side



A
B
C
D

6. P.C.B's PARTS LIST

NOTES:

- Parts without part number cannot be supplied.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%)

560 Ω \rightarrow 56 \times 10¹ \rightarrow 561 RD1/4PS $\begin{matrix} \square & \square & \square \\ 5 & 6 & 1 \end{matrix}$ J
 47k Ω \rightarrow 47 \times 10³ \rightarrow 473 RD1/4PS $\begin{matrix} \square & \square & \square \\ 4 & 7 & 3 \end{matrix}$ J
 0.5 Ω \rightarrow 0R5 RN2H $\begin{matrix} \square & \square \\ 0 & 5 \end{matrix}$ R S K
 1 Ω \rightarrow 010 RS1P $\begin{matrix} \square & \square & \square \\ 0 & 1 & 0 \end{matrix}$ K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors)

5.62k Ω \rightarrow 562 \times 10¹ \rightarrow 5621 RN1/4SR $\begin{matrix} \square & \square & \square & \square \\ 5 & 6 & 2 & 1 \end{matrix}$ F

Mark No.	Symbol & Description	Part No.	Mark No.	Symbol & Description	Part No.
PIN JACK UNIT			DOOR SWITCH UNIT		
OTHERS			SWITCHES		
	JAZZ JACK	PKB1006	S4		RSK1002
REC SWITCH UNIT			MAIN UNIT		
SWITCHES			SEMICONDUCTORS		
	SS SWITCH	RS6-143	IC101		MS220P
TAPE SELECTOR UNIT			IC152 OP-AMP, IC		MS218AP
SWITCHES			IC201		CK20188
	S1, 2	RSB-070	IC251		BA335
CONNECTOR UNIT			IC281		MS218AL
CAPACITORS			IC282		BA6138
	C1	CKCYP473Z50	IC301		CK20188
RESISTORS			IC351 OP-AMP, IC		MS218AP
	R4, E CARBONFILM RESISTOR	RD1/6PM $\begin{matrix} \square & \square & \square & \square \\ & & & \end{matrix}$ J	IC401		MS238PF
SENSOR UNIT(A)			IC551		UPC1297CA
SEMICONDUCTORS			IC701		MS218AL
	D1	GP1A51HR	IC702		MS223L
CAPACITORS			IC731		NJM7812FA
	C2	CKPUYY103N16	IC732		NJM7805FA
RESISTORS			Q101, 102 N-DUAL-PET		2SK389
	R2 CARBONFILM RESISTOR	RD1/6PM $\begin{matrix} \square & \square & \square & \square \\ & & & \end{matrix}$ J	Q103, 104 DIGITAL TRANSISTOR		DTC114TS
SENSOR UNIT(B)			Q281, 282 DIGITAL TRANSISTOR		DTC114TS
SEMICONDUCTORS			Q351-353 DIGITAL TRANSISTOR		DTC114TS
	D2	GP1A51HR	Q355, 356 DIGITAL TRANSISTOR		DTC114TS
CAPACITORS			Q357		DTA114ES
	C3	CKPUYY103N16	Q401, 402 TRANSISTOR		2SD1302
RESISTORS			Q403-414 DIGITAL TRANSISTOR		DTC114TS
	R3 CARBONFILM RESISTOR	RD1/6PM $\begin{matrix} \square & \square & \square & \square \\ & & & \end{matrix}$ J	Q501 TRANSISTOR		DTC124ES
SEMICONDUCTORS			Q502		2SA1283
	D3	GP1A51HR	Q503-505 TRANSISTOR		DTC124ES
CAPACITORS			Q506 TRANSISTOR		2SC3811A
	C4	CKPUYY103N16	Q510, 511		2SC3243
RESISTORS			Q512 TRANSISTOR		2SD1302
	R4 CARBONFILM RESISTOR	RD1/6PM $\begin{matrix} \square & \square & \square & \square \\ & & & \end{matrix}$ J	Q551		DTA114ES
SEMICONDUCTORS			Q552 TRANSISTOR		DTC124ES
	D4	GP1A51HR	Q553 TRANSISTOR		2SA1309A

Mark No.	Symbol & Description	Part No.
OTHERS		
CN31	B8P-SHF-1AA	
CN41 JUMPER CONNECTOR 3-P	KPC3	
JA31 JACK	RKN1014	
OPERATION UNIT		
SEMICONDUCTORS		
Q814	DTA114ES	
Q815 DIGITAL TRANSISTOR	DTC114TS	
Q818 TRANSISTOR	2SA1309A	
Q819, 820	DTA114ES	
Q821, 822	DTC114ES	
Q823	DTA114ES	
D814-822 DIODE	1SS252	
D824 DIODE	1SS252	
D825	SEL2215S	
D826, 827 DIODE	1SS254	
D828, 829 DIODE	1SS252	
SWITCHES		
S801-811 SWITCH	RSG1023	
S813-817 SWITCH	RSG1023	
S821 SWITCH(LINE STRAIGHT)	RSG-150	
S822(DOLBY NR)	RSB1001	
S824 SWITCH(CALIBRATION)	RSG-150	
CAPACITORS		
C821 ELECTR. CAPACITOR	CEAS330M35	
C822, 823 AXIAL CAPACITOR	CKPYB821K50	
RESISTORS		
R814 RESISTOR ARRAY	RA5T□□□J	
R815 CARBONFILM RESISTOR	RD1/6PM□□□J	
R821-828 CARBONFILM RESISTOR	RD1/6PM□□□J	
R975 CARBONFILM RESISTOR	RD1/6PM□□□J	
R977, 978 CARBONFILM RESISTOR	RDF1/4PM□□□J	
VR973 200k-B(REC. BALANCE)	RCV1046	
VR974 5k-B(CALIBRATION)	RCV1044	
VR975 5k-B(CALIBRATION)	RCV1045	
OTHERS		
V801 FL TUBE	RAW1043	
CONTROL UNIT		
SEMICONDUCTORS		
1C801	PD4211	
1C831	BA6109	
1C851	MS233L	
1C861	BA6109	
1C871	TC4050BP	
1C872	MS233L	
Q801-803	DTA114ES	
Q805-809	DTC114ES	
Q810-813	DTA114ES	
Q824	DTA114ES	
Q829	2SD1302	
Q831 DIGITAL TRANSISTOR	DTC114TS	
Q861 TRANSISTOR	2SA1309A	

Mark No.	Symbol & Description	Part No.
Q86C	2SA936	
Q86E TRANSISTOR	2SA1309A	
Q86A DIGITAL TRANSISTOR	DTC114TS	
D801, 802 DIODE	1SS254	
D804, 805 DIODE	1SS254	
D806-809 DIODE	1SS252	
D825	MTZJ9. 1A/B	
D841 DIODE	1SS254	
D845 DIODE	1SS254	
D861	1SR35-100A	
D871-875 DIODE	1SS252	
COILS/TRANSFORMERS		
L831	RTF1068	
CAPACITORS		
C801, 802	CKPYUY103M16	
C805 ELECTR. CAPACITOR	CEAS102M6R3	
C824 ELECTR. CAPACITOR	CEAS103M10	
C825-827	CKPYUY103M16	
C831	CKPYUY103M16	
C832 CERAMIC CAPACITOR	CKCYF473Z50	
C851 AXIAL CAPACITOR	CKPLYB101K50	
C85C CERAMIC CAPACITOR	CKCY147K25	
C85E ELECTR. CAPACITOR	CEAS220M50	
C861	CKPYUY103M16	
C86C ELECTR. CAPACITOR	CEANP487M35	
C86E ELECTR. CAPACITOR	CEASR22M50	
C864 ELECTR. CAPACITOR	CEAS330M35	
C871	CKPYUY103M16	
C87E CERAMIC CAPACITOR	CKCYF473Z50	
RESISTORS		
R801 RESISTOR ARRAY	RA3T□□□J	
R80C RESISTOR ARRAY	RA6T□□□J	
R805 RESISTOR ARRAY	RA4T□□□J	
R804 CARBONFILM RESISTOR	RD1/6PM□□□J	
R80E RESISTOR ARRAY	RA10T□□□J	
R80F RESISTOR ARRAY	RA3T□□□J	
R80T RESISTOR ARRAY	RA11T□□□J	
R808-810 CARBONFILM RESISTOR	RD1/6PM□□□J	
R81C, 813 CARBONFILM RESISTOR	RD1/6PM□□□J	
R81E CARBONFILM RESISTOR	RD1/6PM□□□J	
R81E CARBONFILM RESISTOR	RD1/6PM□□□J	
R82E CARBONFILM RESISTOR	RD1/6PM□□□J	
R831-833 CARBONFILM RESISTOR	RD1/6PM□□□J	
R841, 842 CARBONFILM RESISTOR	RD1/6PM□□□J	
R851-855 CARBONFILM RESISTOR	RD1/6PM□□□J	
R861 METAL GLAZE RESISTOR	RS1LMF□□□J	
R86C-867 CARBONFILM RESISTOR	RD1/6PM□□□J	
R871 RESISTOR ARRAY	RA5T□□□J	
R87C	RCX1020	
R87E, 874	RN1/6PC□□□□F	
OTHERS		
X801 CERAMIC RESONATOR	YSS1014	

Mark No.	Symbol & Description	Part No.
TIMER UNIT		
SWITCHES		
S981(TIMER)		RSH1011
INPUT VR UNIT		
RESISTORS		
R971, 972 CARBONFILM RESISTOR		RDR1/2PM□□□J
VR971		RCV1047
OTHERS		
CN31 CONNECTOR		SSQ-8-A
JA11 JACK		PXB1005
HEADPHONE UNIT		
SEMICONDUCTORS		
IC901 OP-AMP, IC		MS218AP
CAPACITORS		
C901, 902 ELECTR. CAPACITOR		CEYA010M50
C903, 904 ELECTR. CAPACITOR		PCH1076
RESISTORS		
R901-906 CARBONFILM RESISTOR		RD1/6PM□□□J
R907, 908 CARBONFILM RESISTOR		RDR1/4PM□□□J
R909, 910 CARBONFILM RESISTOR		RD1/6PM□□□J
VR901 20k-B(PHONES LEVEL)		RCV1043
OTHERS		
JA51 JACK		RKN1002
POWER SWITCH UNIT		
SWITCHES		
S991 SWITCH(POWER)		RSA-063
CAPACITORS		
C991 CAPACITOR (CERAMIC)		VCG-044

7. ADJUSTMENTS

7.1. MECHANISM RELATED ADJUSTMENT

1. Tape Speed Adjustment		
Mode	Adjustment Location	Specifications
PLAY	Capstan motor adjustment hole (Refer to Fig. 1.)	Adjust so that the playback frequency is 3015 ± 5 Hz at the beginning of winding of test tape STD-301.
PLAY		Playback test tape STD-301 again and confirm that the above specifications are satisfied.




Fig. 1.

2. Adjustment of Door Damper	
Adjustment Location	Specifications
Cylinder adjustment screw (Refer to Fig. 2.)	Make sure that the door opens smoothly, there is no two-stage motion, and that there is no bounding when it opens completely. (Perform with no cassette half inserted.)




Fig. 2.

7.2 ELECTRICAL ADJUSTMENTS

Adjustment Conditions

- The mechanical adjustments must be completed first.
- The head must be cleaned and demagnetized.
- Turn power on allow the deck to warm up for at least a few minutes before commencing any electrical adjustments.
- The reference signal is $0dBv=1V_{rms}$.
- Connect a 50 kΩ (or between 47k to 52 kΩ) load resistance to the OUTPUT terminals.
- Unless otherwise specified, the switches listed below are left in the positions indicated.
 DOLBY NR : OFF
 TAPE SELECTOR : NORM

Test Tapes

- STD-331B : Playback adjustments (See Fig. 7-1)
 STD-630 : NORMAL blank tape
 STD-620 : CrO₂ blank tape
 STD-610 : METAL blank tape

List of Adjustments

Playback sections

- Head azimuth adjustment.
- Playback level adjustment.

Recording sections

- Bias oscillator adjustment.
- Recording bias adjustment.
- Recording level adjustment.
- Level meter adjustment.
- DC balance adjustment
- Recording level and recording bias calibration adjustment.

NOTE: This unit has an automatic tape selection feature.




Fig. 7-1 Constants of the test tape STD-331B




Fig. 7-2 Head azimuth adjustment




Fig. 7-3 Frequency response zone

PLAYBACK SECTION

1. Head Azimuth Adjustment

* Turn VR105, VR106 to mechanical center positions.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	PLAY	Play the 10 kHz/-20 dB section of STD-331B test tape.	Head azimuth adjustment screw. (See Fig. 7-2)	LINE OUT	Maximum playback signal level.	
2.	STOP	Lock the screw with screw lock after completing adjustment.				

2. Playback level Adjustment

* This adjustment determines the DOLBY NR level, and must be performed with great care.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	PLAY	Play the 315 Hz/0 dB section of the STD-331B test tape.	Deck I VR105 (Lch) VR106 (Rch)	TP. 3 (Lch) TP. 4 (Rch)	-14.7 dBv	




Fig. 7-4 Adjustment points

RECORDING SECTION

1. Bias Oscillator Adjustment

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC/PLAY	Load the STD-610 test tape with no input signal.	Deck I L 505	TP. 11	106 kHz ± 300 Hz	

2. Recording Bias Adjustment

* Since the STD-630 recording bias adjustment determines the calibration standard, it should be performed carefully.

2-1. Overbias Adjustment							
No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks	
1.	REC/PAUSE	Apply a 6.3 kHz/10 dBv (-10VU meter reading) signal to the Line input terminals and insert STD-630.	-	LINE OUT	-		
2.	REC →PLAY	Record and play back the 6.3 kHz signal at -10 dBv input level.	NOR	VR551 (L) VR552 (R)	NOR	3.0 dB overbias	Turn control clockwise past the peak to assure proper overbias value.
3.		Record the 6.3 kHz/-10 dBv signal on STD-620 and play back.	CrO ₂	VR501 (L/R)	CrO ₂	2.5 dB overbias	
4.		Record the 6.3kHz/-10 dBv signal on STD-610 and play back.	METAL	VR502 (L/R)	METAL	1.0 dB overbias	
5. Turn control clockwise past the peak to assure proper overbias value.							

2-2. Frequency Response Adjustment

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC/PAUSE	Apply a 10kHz/315 Hz/-20 dBv signal to the Line input terminals and insert STD-630.	-	LINE OUT	-	
2.	REC →PLAY	Record and play back the 315 Hz signal and a 10 kHz signal at -20 dBv input level.	NOR	VR551 (L) VR552 (R)		Record and play back repeatedly, comparing the 315 Hz and 10 kHz playback levels, and adjust to 0 ± 0.5 dB.
3.		Record the 10 kHz/315 Hz, -20 dBv signal on STD-620 and play back.	CrO ₂	VR501 (L/R)		0 ± 1.0 dB
4.		Record the 10 kHz/315 Hz, -20 dBv signal on STD-610 and play back.	METAL	VR502 (L/R)		0 ± 1.0 dB
5. Check distortion value after adjustment is completed and confirm that there is no underbias.						

3. Recording Level Adjustment

* Since the STD-630 recording level adjustment determines the calibration standard, it should be performed carefully.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	STOP	Set the TAPE SELECTOR switch to the NORM position.				
2.	REC PAUSE	Apply a 315 Hz/0 dBv signal to the line input terminals, load the STD-630 test tape.	Rec Level control volume	TP. 3 (Lch) TP. 4 (Rch)	-15.2 dBv	
3.	STOP	Set the DOLBY NR switch to the ON position. (DOLBY B)				
4.	REC/ PLAY	Record the above signal onto the STD-630 test tape, and playback.	Deck 1 VR401 (Lch) VR402 (Rch)	TP. 3 (Lch) TP. 4 (Rch)	Repeatedly record, playback and adjust so that the playback signal level becomes -15.2 dB.	
5.	STOP	Set the TAPE SELECTOR switch to the CrO ₂ position.				
6.	REC/ PLAY	Record the above signal onto the STD-630 test tape, and playback.	Check	TP. 3 (Lch) TP. 4 (Rch)	-15.2 dBv ± 1.5 dB	
7.	STOP	Set the TAPE SELECTOR switch to the METAL position.				
8.	REC/ PLAY	Record the above signal onto the STD-610 test tape, and playback.	Check	TP. 3 (Lch) TP. 4 (Rch)	-15.2 dBv ± 1.5 dB	

4. Level Meter Adjustment

* Adjust by turning clockwise until the lamp lights up.


No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC PAUSE	Apply a 315 Hz/-10 dBv (316 mV) signal to the Line input terminals.	VR281 (Lch) VR282 (Rch)	TP. 1 (Lch) TP. 2 (Rch)	Always set the enlarged mode when adjusting. Adjust so that the 0 dB segment lights at a level of -15.2 ± 0.5 dBv (-15.2 ± 1.0 dBv in the normal model).	

5. DC Balance Adjustment

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.			VR101 (Lch) VR102 (Rch)	TP17 (Lch) TP18 (Rch)	0V ± 0.2V	

6. Recording Level and Recording Bias Calibration Adjustment.

* This adjustment should be performed last.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC/ PLAY	Load the STD-630. Calibration switch: ON Recording level calibration potentiometer: Center click position Recording bias calibration potentiometer: Center click position	LEVEL CAL. (400 Hz) VR351 BIAS CAL. (10 kHz) VR352	Level meter	The meter should light up to the LEVEL or BIAS arrow position.  Adjust to the point immediately before the segment to the right of the arrow lights.	

8. FOR HB TYPE

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts without part number cannot be supplied.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "Q" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

The CT-959/HB type is the same as the CT-959/HEM type with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		CT-959/ HEM type	CT-959/ HB type	
Δ	AC power cord Operating instructions (French, Italian, Dutch, Swedish, Portuguese, Spanish)	ADG1036 RRD1078	PDG1004	

LINE VOLTAGE SELECTION


Line voltage can be changed with the following steps.

1. Disconnect the AC power cord.
2. Remove the top cover.
3. Change the transformer wire (To POWER SW UNIT) of terminal CN92-2 and CN92-3 as follows.

Voltage	Terminal No. CN92-2	Terminal No. CN92-3
220V	RED	GRAY
240V	GRAY	RED

4. Stick the line voltage label on the rear panel.


Parts NO.	Description
AAX-193	220V label
AAX-192	240V label



9. PANEL FACILITIES

Front panel

The illustration shows model CT-959



① **POWER switch**

② **Cassette door**

③ **Cassette door OPEN/CLOSE button**

④ **TAPE RETURN button**

When this button is pressed, the tape will be fast forwarded or reversed until the tape counter reaches the "0000" range.

⑤ **COUNTER MODE button**

When pressed, the mode will change in sequence.

- TAPE COUNTER
- TIME COUNTER (displays elapsed time of recording or playback)
- REMAIN counter (displays time remaining on the tape) (CT-959 only)

For CT-959

⑥ **COUNTER RESET/TAPE CAPACITY button**

This button resets the counter display when in the TAPE COUNTER or TIME COUNTER modes. In the REMAIN mode, tape type indication will change every time the button is pressed, for setting of the tape type to be used.

— C60—C46L—C90—C80L—

For CT-757

⑥ **COUNTER RESET button**

This button resets the counter display when in the TAPE COUNTER or TIME COUNTER modes.


⑦ **DISPLAY OFF button**

To turn on/off the FL display.

⑧ **REC LEVEL control knob**

⑨ **DOLBY* NR selector**

To select Dolby type-B, type-C NR system and OFF.

- *Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.*
- *"Dolby", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.*

⑩ **LINE STRAIGHT button (CT-959 only)**

Bypasses recording balance volume.

⑪ **REC BALANCE knob**

⑫ **CD SYNCHRO button (CD SYNC)**

For automatic operation when recording a CD from a Pioneer CD player compatible with the CD-DECK SYNCHRO function.

⑬ **MONITOR (AUTO) selector**

Switches SOURCE/TAPE sound when monitoring recording.

⑭ **TIMER selector**

REC: To record by timer.

OFF: To switch the timer or repeat functions off. Normally set to this position.

PLAY/REPEAT:

To play back by timer. When the switch is set to this position during normal playback, one side will be played back repeatedly (repeat playback).

⑮ **Headphones level knob (PHONES LEVEL)**

⑯ **Headphones jack (PHONES)**

⑰ **Operation buttons**

Recording button (●):

When this button is pressed, the mode will change to one-touch recording Pause (recording standby).

Recording will be started with the Pause (⏸) button or the Play (▶) button.

Pause button (⏸):

When this button is pressed, recording or playback will be stopped temporarily. To resume recording/playback, press the button again. This function does not work during Fast Forward or Rewind mode.

Recording mute button (⊖):

Produces a blank space during recording.

Play button (▶):

Stop button (■):

Rewind button (◀◀):

To rewind a tape. When this button is pressed during playback, the song being played back is rewound to the beginning. When this button is pressed twice, the song being played back is rewound to the beginning of the previous song.

Fast Forward button (▶▶):

To fast forward a tape. When this button is pressed during playback, the song being played back is forwarded to the beginning of the next song. When this button is pressed twice, the song being played back is fast forwarded to the beginning of the song following the next song.

⑱ **METER RANGE selector**

Switches the scale range (wide/expanded) of the level meter.

⑲ **METER HOLD MODE button**

Switches between the mode where the peak level lights for 1.2 seconds and the mode where the peak level lighting is continuous.

⑳ **CALIBRATION-BIAS control knob**

Changes the sound by increasing/decreasing the recording bias.


㉑ **CALIBRATION-ON/OFF button**

To set an optimum bias and level for the tape.

㉒ **CALIBRATION-LEVEL control knob**

Adjusts recording sensitivity according to the tape in use.

Indicator



① Travelling mode indicator

- ◀◀: Lights during rewinding mode.
- ▶: Lights during playback, playback/recording Pause, and recording mode. Blinks during MUSIC SEARCH mode.
- ▶▶: Lights during fast forward mode.
- : Lights during pause mode.

② Counter dispays (TAPE, TIME etc)

- Displays in three modes (CT-757 is two modes).
- Displays the number of songs during MUSIC SEARCH mode.

③ TIME counter mode

The numbers are lighted during TIME COUNTER mode.

④ REMAIN mode (CT-959 only)

The numbers are lighted during REMAIN mode.

⑤ Recording level (LEVEL)

Lights when the CALIBRATION ON/OFF button is pressed.

⑥ Return mode (RETURN)

Lights during tape return operation.

⑦ Tape type (NORM, CrO₂, METAL)

Displays the tape type (NORMAL/CrO₂/METAL) detected.

⑧ Wide range meter scale

⑨ Recording (REC)

Lights during recording.

⑩ Muting (MUTE)

Blinks when muting the recording.

⑪ PEAK HOLD

Lights/goes off when the METER HOLD MODE button is turned ON/OFF.

⑫ Monitor source (TAPE/SOURCE)

TAPE: Sound of tape
SOURCE: Sound of source

⑬ Recording bias (BIAS)

Lights when the CALIBRATION ON/OFF button is pressed.

⑭ CD-DECK SYNCHRO (CD SYNC)

Lights when the CD-SYNCHRO function is functioning.

⑮ Expand range meter scale

⑯ DOLBY B-TYPE NR/C-TYPE NR

Displays either DOLBY B-type or C-type NR system.

⑰ Level meter

L: Left channel
R: Right channel
Holds peak indications for about 1.2 second. □□ (double D) symbol beside the +3dB mark indicates the Dolby NR systems standard level.

⑱ Dolby HX PRO indicator

This unit is provided with a built in Dolby HX PRO Headroom Extension circuit. The Dolby HX PRO Indicator always appears on the display when the POWER switch is turned on.

10. SPECIFICATIONS

System	4-track 2-channel stereo
Heads	Recording/playback head (Combined amorphous recording/amorphous playback head) × 1 Erasing head (Double-gap ferrite head with sendust) × 1
Motor	DC servo capstan motor × 1 DC reel motor × 1 DC assist motor × 1
Wow and flutter	±0.022% (WRMS) ±0.052% (DIN)
Fast-winding time	Approx. 80 sec. (C-60 tape)
Frequency characteristics (-20 dB recording)	Metal tape 15 Hz to 22,000 Hz CrO ₂ tape 15 Hz to 21,000 Hz Normal tape 15 Hz to 21,000 Hz
Signal-to-Noise Ratio	DOLBY NR OFF More than 60 dB
Noise reduction effect	DOLBY B-type NR ON More than 10 dB (at 5 kHz) DOLBY C-type NR ON More than 19 dB (at 5 kHz)
Harmonic distortion	No More than 0.8% (0 dB)
Input	LINE: 60 mV (Input impedance: 47 kΩ)
Output	LINE: 316 mV (Output impedance: 1.8 kΩ) Head phones: 2.3 mW (Load impedance 8Ω, VR max.)

Miscellaneous

Power requirements	European model a.c. 220 V ~, 50/60 Hz U.K. model a.c. 240 V ~, 50/60 Hz
Power consumption	24W
Dimensions	420 (W) × 134.5 (H) × 370 (D) mm 16.9/16 (W) × 5.5/16 (H) × 14.9/16 (D) in.
Weight	approx. 3.4 kg (16 lb 7 oz)

Accessories

Operating instructions	1
Connection cord	2
CD-DECK SYNCHRO cord	1

NOTE:
Specifications and design subject to possible modifications without notice, due to improvements.

Functions

- 3-mode counter
- ATLC (Auto Tape Loose Canceler)
- Meter range (wide/expanded) selector
- AUTO MONITOR
- Power eject (OPEN/CLOSE)
- MUSIC SEARCH
- TAPE RETURN/RETURN Play
- Headphones jack (with level control)
- LINE STRAIGHT
- DISPLAY OFF
- CD-DECK SYNCHRO
- PEAK LEVEL CALIBRATION system
- REC CALIBRATION (BIAS/LEVEL, built-in oscillator)
- MPX filter switch
- AUTO RECORDING MUTE
- Auto tape selector
- Timer start function recording/playback - REPEAT playback
- Dolby B-type and C-type Noise Reduction systems
- Dolby HX-PRO system
- Level meter: 2-mode PEAK HOLD selector