

**'TRADER' SERVICE SHEETS**

**BURNDEPT 201, 225,  
226 AND 231**

**A** 4-VALVE (plus rectifier) A.C. superhet chassis is fitted in the Burndept 201 receiver, the valve arrangement comprising an octode frequency changer, a variable-mu pentode I.F. amplifier, a double diode and a pentode output valve.

The chassis is suitable for A.C. mains of 195-260 V., 40-100 c.p.s., and has provision for a gramophone pick-up, an extension speaker and for using the mains as an aerial. Features are a meter type visual tuning indicator and two separate speakers.

A similar chassis is fitted in the 225 radio-gramophone, and in the 226 and 231 table models, but the last two have only a single speaker.

**CIRCUIT DESCRIPTION**

Aerial input by way of **S1** (L.W.) and **S2** (M.W.) to tapplings on primary of inductively coupled band-pass filter.

Primary **L1, L2**, tuned by **C26**; secondary **L7, L8**, tuned by **C28**; coupling coils **L3, L4, L5, L6**.

First valve (**V1, Mullard metallised FC4**) is an octode operating as frequency changer with electron coupling. Oscillator grid coils **L9, L10**, tuned by **C30**; anode reaction coils **L11, L12**; tracking by pre-set condenser **C32** (L.W.) and fixed condensers **C6, C7** (M.W.).

Second valve (**V2, Mullard metallised VP4A**) is a variable-mu H.F. pentode operating as intermediate frequency amplifier with tuned-primary, tuned-secondary transformer couplings **L13, L14** and **L15, L16**.

Intermediate frequency 130 KC/S.

Visual tuning indicator of moving iron type in common anode feed circuit to **V1** and **V2**.

There is provision for insertion of pick-up in grid circuit of **V2** by means of switch **S7**. **S6** disconnects the radio input


on Gram. **V2** acts as L.F. amplifier on Gram., with anode load **R9**, and coupling condenser **C17**.

Diode second detector forms part of double diode (**V3, Mullard metallised 2D4A**). Second diode provides steady potential, developed across **R13, R14** and **R15**, which is fed back as G.B. to **V1** and **V2**, giving automatic volume control. Delay voltage is obtained from voltage drop along **R19**, which also acts as **V4** bias resistance.

Audio frequency output from rectifier diode is developed across **R11** and passed by way of I.F. stopper **R12**, and coupling condenser **C15** to manual volume control **R17**, thence via grid stopper **R18** to control grid of output pentode (**V4, Mullard Pen4VB**). Fixed tone compensation by **C20**, and variable tone control by **C21** and **R20**. Provision for connection of high resistance external speaker, through coupling and isolating condenser **C22**.


H.T. current supplied by I.H.C. full-wave rectifying valve (**V5, Micromesh R2** or **R3**). Smoothing by speaker field **L20** and dry electrolytic condensers **C23, C24**.

In models CN201 and CN225, the energised speaker **L18, L19, L20** is supplemented by a P.M. type, **L17**, in parallel with **L18, L19**. In models CN226 and CN231, only the energised speaker is fitted.



Circuit diagram of the Burndept 201 A.C. superhet. The 225 radio-gramophone has a similar chassis, while the only difference in the 226 and 231 models is that there is only a single speaker. In some chassis **R16** and **C17** may be transposed.

Under-chassis view. The switches S1-S7 are clearly marked. C20 is beneath the electrolytic block C23 and C24. C32, the L.W. oscillator padder, is adjusted through a hole in the chassis deck.



**COMPONENTS AND VALUES**

Resistances		Values (ohms)
R1	V1 pentode C.G. decoupling ..	100,000
R2	V1 pentode anode and V2 anode H.T. feed ..	5,000
R3	V1 fixed G.B. resistance ..	250
R4	V1 oscillator grid resistance ..	50,000
R5	V1 S.G.'s and oscillator anode H.T. feed ..	30,000
R6	V2 C.G. decoupling ..	250,000
R7	V2 S.G. potential divider ..	25,000
R8	V2 S.G. potential divider ..	20,000
R9	V2 anode load (for gram.) ..	10,000
R10	V2 fixed G.B. resistance ..	200
R11	V3 signal diode load ..	1,000,000
R12	I.F. stopper ..	100,000
R13	V3 A.V.C. diode load ..	500,000
R14	V3 A.V.C. diode load ..	500,000
R15	V3 A.V.C. diode load ..	250,000
R16	Limiting resistance ..	250,000
R17	Manual volume control ..	500,000
R18	V4 C.G. I.F. stopper ..	100,000
R19	V4 G.B. and V3 delay voltage resistance ..	150
R20	Variable tone control ..	250,000

Condensers		Values (μF)
C1	V1 C.G. decoupling ..	0.1
C2	V1 pentode anode and V2 anode decoupling ..	0.1
C3	V1 S.G.'s by-pass ..	0.1
C4	V1 cathode by-pass ..	0.1
C5	V1 oscillator C.G. condenser ..	0.001
C6	V1 oscillator C.G. condenser ..	0.0005
C7	Osc. M.W. trackers, fixed ..	0.01
C8*	V1 S.G.'s and oscillator anode decoupling ..	8.0
C9	V2 C.G. decoupling ..	0.1
C10	V2 S.G. by-pass ..	0.1
C11	V2 anode by-pass ..	0.002

Condensers—(con't.)		Values (μF)
C12	V2 cathode by-pass ..	0.1
C13	I.F. by-pass ..	0.0001
C14	Coupling to V3 A.V.C. diode ..	0.0001
C15	L.F. coupling to V4 ..	0.01
C16	I.F. by-pass ..	0.0001
C17	L.F. coupling (gram.) ..	0.01
C18	Vol. control shunt ..	0.0001
C19*	V3 cathode by-pass ..	50.0
C20	Tone corrector ..	0.002
C21	Tone control condenser ..	0.1
C22	Ext. L.S. coupling ..	0.5
C23*	H.T. smoothing ..	8.0
C24*	H.T. smoothing ..	16.0
C25	Mains aerial coupling ..	0.0001
C26†	Band-pass primary tuning ..	—
C27‡	Band-pass primary trimmer ..	—
C28†	Band-pass secondary tuning ..	—
C29‡	Band-pass secondary trimmer ..	—
C30†	Oscillator tuning ..	—
C31†	Oscillator trimmer ..	—
C32‡	Oscillator L.W. tracker ..	—
C33‡	1st I.F. trans. pri. tuning ..	—
C34‡	1st I.F. trans. sec. tuning ..	—
C35‡	2nd I.F. trans. pri. tuning ..	—
C36‡	2nd I.F. trans. sec. tuning ..	—

\* Electrolytic. † Variable. ‡ Pre-set.

Other Components		Approx. Values (ohms)
L1	Band-pass primary coils	4.9
L2		9.5
L3		9.5
L4	Band-pass coupling coils (in parallel)	0.2
L5		0.2
L6		0.2
L7	Band-pass secondary coils	4.9
L8		9.5
L9	Oscillator grid tuning coils	4.1
L10		5.75

Other Components—(con't.)		Approx. Values (ohms)
L11	Oscillator anode reaction coils	0.8
L12		1.9
L13	1st I.F. trans.	26.0
L14		26.0
L15	2nd I.F. trans.	26.0
L16		26.0
L17	P.M. speaker speech coil ..	2.6
L18	Energised speaker speech coil ..	2.6
L19	Hum neutralising coil ..	0.1
L20	Speaker field coil ..	2,000.0
T1	Speaker input trans.	750.0
		0.4
T2	Mains trans.	0.03
		400.0
		—
S1-S5	Waveband switches ..	—
S6	Radio muting switch (gram.) ..	—
S7	Gram. pick-up switch ..	—
S8	Mains switch, ganged R17 ..	—
T.I.	Tuning indicator ..	2,000.0

**DISMANTLING THE SET**

**Removing Chassis.**—To remove the chassis from the cabinet, first remove the back (eight round-head wood screws and washers) and the four control knobs (recessed grub screws). Now remove the two bolts (with two washers and a rubber washer each) holding the front of the chassis to the bottom of the cabinet and the two bolts (with nuts, lock washers and washers) holding the back of the chassis. The chassis can now be withdrawn to the extent of the speaker leads, which is just sufficient for normal purposes.

(Continued overleaf)

DEPT 201, 225, 226, and 231 (Continued)

placing, do not forget to re-rubber washers and washers the front of the chassis and the bottom and note that the control knob is not marked with a white line the spindle of the tuning dial. Unsolder the chassis entirely, unsolder the energised speaker. When connect the leads as follow:—joined together, black; 1, blue;

**ng Speakers.**—To remove the from the cabinet, first disconnect Each speaker is held to its by four bolts and can be by taking off the nuts and lock from these. When replacing permanent-magnet speaker are to the outer of the three tags strip carrying the connections speech coil. When replacing speaker, make sure that they are d exactly as before, otherwise l be out of phase. If in doubt, possible ways of connection and at which gives the better results.

**VALVE ANALYSIS**

voltages and currents given in le below are those measured in eiver when it was operating on of 225 V, using the 230 V tapping mains transformer. The volume was at maximum and the receiver ned to the lowest wavelength on edium band, but there was no input. ages were measured on the 1,200 V of an Avometer, with chassis ative.

Valve	Anode Volts	Anode Current (mA)	Screen Volts	Screen Current (mA)
2A*	280	0.3†	80	5.1
24A	220	4.9	95	2.1
44A	—	—	—	—
44VB	255	42.0	290	5.3
3	380†	—	—	—


Osc. anode (G2) 80 V, 2.2 mA.  
Each anode, A.C.  
2.4 mA at top of tuning scale.

**GENERAL NOTES**

switches.—S1-S5 are the waveband ches, S6 the radio muting switch n.) and S7 the gramophone pick-up ch. These are all ganged in a single beneath the chassis, seen in our r-chassis view. The table below s the switch positions for the various rol settings, O indicating open, and used.

Switch	M.W.	L.W.	Gram.
S1	O	C	O
S2	C	O	O
S3	C	O	O
S4	C	O	O
S5	C	O	O
S6	C	C	O
S7	O	O	C

S8 is the Q.M.B. mains switch, ganged h the volume control R17.



Plan view of the chassis. C32 is the oscillator L.W. trimmer. A moving iron tuning indicator is fitted.

**Coils.**—L1-L12 are in three screened units, while the I.F. transformers, L13, L14, and L15, L16 are in two further screened units. All are mounted on the chassis deck.

**Scale Lamp.**—This is an Osram M.E.S. type, rated at 6.5 V, 0.3 A.

**External Speaker.**—Two sockets are provided at the rear of the chassis for a high resistance external speaker.

**Tuning Indicator.**—This is mounted above the tuning scale in an exposed position, and as it is rather fragile, care should be taken, when working on the underside of the chassis, to see that the indicator is not resting on the bench.

**Condensers C23, C24.**—These are two dry electrolytics in a single unit beneath the chassis. The black lead is the common negative, the yellow the positive of C23 (8 μF) and the red the positive of C24 (16 μF).

**Condenser C20.**—This is beneath the C23, C24 unit, and is shown dotted in our under-chassis view.

**Tracker C32.**—The L.W. oscillator tracker is adjusted through a hole in the chassis deck between the V1 and V2 valve-holders.

**Components C17, R16.**—These may be transposed in some chassis.

**CHASSIS DIVERGENCIES**

Models CN201, 225, 226 and 231 at present have similar chassis, but as explained at the end of the circuit description, Models CN201 and 225 have an additional P.M. speaker.

Earlier versions of these four chassis differed in a number of points, the most important circuit modification being the feeding of the pick-up directly across the volume control, instead of using V2 for amplification as at present. Further, there were minor differences in component values (C23 and C24 were 6 μF each in early table models), while C7 was omitted in a few very early models, and the I.F. was 117.5 KC/S.

The layout of the underside of the chassis was different, a condenser and resistance strip stretching from the front to the rear of the chassis.

Where an early model is received for service, reference should be made to Service Sheet No. 40 dealing with the then current Model CN226.

**CIRCUIT ALIGNMENT**

**I.F. Stages.**—Set receiver tuning pointer to bottom of L.W. scale. Connect oscillator grid of V1 (Pin 2) to chassis. Connect a 250,000 Ω resistance between pentode control grid (top cap) of V1 and chassis, and leave the existing top cap lead disconnected. Inject a 130 KC/S signal between top cap and chassis. Fit a 10,000 Ω resistance with crocodile clips on short leads at the ends, and use it as a shunt across the primary of an I.F. transformer when the secondary is being adjusted, and vice-versa.

Working on this principle, and with an output meter (say a 0-100 V A.C. voltmeter) plugged into the external speaker sockets, adjust C36, C35, C34 and C33 in turn for maximum output, in that order. Keep the input low to avoid A.V.C. influence.

**H.F. and Oscillator Stages.**—Turn tuning knob until gang condenser is fully in mesh. Scale pointer should now cover the spot at the top end of the scale, about 1/2 in. to the right of the 2,000 m. mark.

Now adjust tuning knob so that pointer indicates 200 m., inject a 200 m. signal at the A. and E. sockets, and adjust C31 for maximum output.

Inject a 220 m. signal, set tuning pointer to 220 m., and adjust C27 and C29 for maximum output, rocking the tuning knob slightly to obtain the optimum point.

Switch receiver to L.W., set pointer to 2,000 m., inject a 2,000 m. signal, and adjust C32 for maximum, slightly rocking the tuning knob meanwhile.