


# ICF-54501

*AEP Model*  
*UK Model*



## 3-BAND PORTABLE RADIO


### SPECIFICATIONS

<b>Circuit:</b>	Superheterodyne	<b>Power Requirements:</b>	DC: 4.5 V Battery size-C, 3 pcs Car battery cord DCC-127H for 12-V car battery
<b>Aerials:</b>	FM: telescopic antenna (7 steps, 86 cm) LW, MW: ferrite-rod (10 mm dia x 180 mm)	AC:	240 V, 50 Hz with Sony AC Power Adaptor AC-14 (UK model), 110, 220 V, 50/60 Hz with Sony AC Power Pack AC-456C or AC-3W (AEP model)
<b>Frequency Ranges:</b>	FM: 87.5 – 108 MHz (3.43 – 2.78 m) LW: 160 – 285 kHz (2,000 – 1,050 m) MW: 530 – 1,605 kHz (566 – 187 m)	<b>Current Drain:</b>	DC 45 mA with no signal input at AM DC 50 mA with no signal input at FM
<b>Intermediate Frequencies:</b>	FM: 10.7 MHz LW/MW: 468 kHz	<b>Maximum Power Output:</b>	1,800 mW at 10% distortion
<b>Jacks:</b>	Earphone jack Record out jack MPX OUT jack EXT POWER IN DC 4.5 V TIMER IN jack	<b>Speaker:</b>	10 cm (4 inches) dia, 8 Ω
		<b>Semiconductors:</b>	10 transistors, 6 diodes, 1 IC 1 FET
		<b>Dimensions:</b>	248 (w) x 160 (h) x 70 (d) mm 9¾ (w) x 6¼ (h) x 2⅞ (d) inches
		<b>Weight:</b>	1.3 kg, 2 lb 15 oz with batteries


**SONY**<sup>®</sup>  
**SERVICE MANUAL**

## SECTION 1 OUTLINE


### 1-1. BLOCK DIAGRAM



## 1-2. EXTERNAL VIEW




## 1-3. INTERNAL VIEW




**SECTION 2  
DISASSEMBLY**

**2-1. DIAL FILM ATTACHMENT**



1 Put the protrusion of the film drum into the hole of the film chassis.




2 Turn the follower gear to the arrowed direction to eliminate any slack of the dial film. Holding the dial film not to be unwound, further turn the gear to wind the spring up.

3 Pull off the drive gear not to gang with the follower gear.

4 Put the drive gear in to gang with the follower gear.

	FM	MW	LW
88		530	150
90		600	160
92		700	180
94		800	200
96			
98			



5 Rotate the tuning shaft to the full counterclockwise position.

6 Make a fine adjustment to the follower gear so that the markings on the dial film place as illustrated in the inset.

7 Turn the drive gear so that the markings on the dial film place as illustrated in the inset.


8 Attach the film chassis to the chassis.

2-2. REMOVALS


REAR CASE REMOVAL

Remove rear case by removing four screws, P 3 x 52.


CHASSIS REMOVAL




TIMER REMOVAL




CONTROL CIRCUIT BOARD REMOVAL




VOLUME CONTROL CIRCUIT BOARD REMOVAL




FILM CHASSIS REMOVAL





TUNING METER REMOVAL



AFC SWITCH CIRCUIT BOARD REMOVAL



MAIN CIRCUIT BOARD REMOVAL



SECTION 3  
ADJUSTMENTS

Test Equipment/Tools Required:


- AM rf signal generator
- FM rf signal generator
- VTVM
- VOM
- Loop antenna
- Lead antenna
- 8 Ω, 2 W resistor

Note: 1. Modulation

- AM: 30% amplitude modulation by 400 Hz signal.
- FM: ±22.5 kHz frequency deviation modulated by 400 Hz signal.

2. AM, FM rf signal generator output level should be useable lowest possible for the following adjustments.

3. When 0.5~1.5V AC range is not available on the VOM, use a tuning meter together with the network as shown below.




D1, 2: germanium power transistor, 2SB495, etc.

1. AM 1-f Alignment


The ICF-5450L uses a ceramic filter (CFA) for AM (i.e. MW and SW) which is not able to be adjusted using an ordinary a-m signal generator—VOM method. Do not adjust the cores of CFA unless otherwise needed.

Note: Replacement CFA is carefully preadjusted at the factory, and no adjustment is needed when a new CFA is used in place of any defective CFA.

When an adjustment is needed to CFA by all means, use a sweep-marker generator and an oscilloscope, and obtain a frequency response as shown below.



Adjustment Location:




2. LW Frequency Coverage and Tracking Adjustments

Settings:

- BAND SELECTOR switch: LW
- VOLUME control: MAX
- TONE controls: MAX

Procedure:





Adjustment	Step	AM rf signal generator frequency	Tuning knob	Adjust	VOM reading
Frequency Coverage	1	145 kHz	fully counter-clockwise	L12	maximum
	2	300 kHz	fully clockwise	CT3	maximum
Tracking	1	180 kHz	tune in 3.8 MHz	L10	maximum
	2	260 kHz	tune in 12.3 MHz	CT5	maximum

Note: Repeat above steps two or three times until desired result is obtained ending with steps 2.

\*When adjusting CT5, remove the TIMER.

Adjustment Locations: frequency coverage




3. MW Frequency Coverage and Tracking Adjustments

Settings:

- BAND SELECTOR switch: MW
- VOLUME control: MAX
- TONE controls: MAX

Procedure:





Adjustment	Step	AM rf signal generator frequency	Tuning knob	Adjust	VOM reading
Frequency Coverage	1	520 kHz	fully counter-clockwise	L11*	maximum
	2	1,680 kHz	fully clockwise	CT4	maximum
Tracking	1	620 kHz	tune in 620 kHz	L9	maximum
	2	1,400 kHz	tune in 1,400 kHz	CT6	maximum

Note: Repeat above steps two or three times until desired result is obtained ending with step 2. Fix L9 with wax after adjustment.

\*When adjusting L11, remove the band selector switch slider.

Adjustment Locations: 82.6 x 6, self-tapping L11\* CT4





**4. FM I-f Alignment and Discriminator Adjustment**



**Settings:**

BAND SELECTOR switch: FM  
 VOLUME control: MAX  
 TONE controls: MAX  
 AFC switch: OFF

**Procedure:**




VOM connection for step 4.



Step	FM rf signal generator frequency	Tuning knob	Adjust	VOM reading
1	10.7 MHz with FM modulation	No station, no beating position	Rf signal generator frequency	maximum
2	- ditto -	- ditto -	IFT F1-3	maximum
3	Repeat steps 1 and 2 (two or three times).			
4	Turn modulation off. Increase output a little.	- ditto -	IFT F3	"0 V DC"

**Adjustment Location:**




**5. FM Frequency Coverage and Tracking Adjustments**

**Settings:**

BAND SELECTOR switch: FM  
 VOLUME control: MAX  
 TONE controls: MAX

**Procedure:**




Adjustment	Step	AM rf signal generator frequency	Tuning knob	Adjust	VOM reading
Frequency Coverage	1	87.1 MHz *	fully counter-clockwise	L5	maximum
	2	108.5 MHz *	fully clockwise	CT2	maximum
Tracking	1	87.1 MHz *	fully counter-clockwise	L3	maximum
	2	108.5 MHz *	fully clockwise	CT1	maximum

\* In the Federal Republic of Germany, the frequencies should be 87.5 and 108 MHz.

Note: Repeat above steps two or three times until desired result is obtained ending with steps 2. Fix L3 with wax after adjustment.

**Adjustment Locations:**




**6. LW Maximum Sensitivity Measurement**

**Settings:**

BAND SELECTOR switch: LW  
 VOLUME control: MAX  
 TONE controls: MAX

**Procedure:**



Note: Distance between center of loop antenna and center axis of MW ferrite-rod antenna are dependent upon the specifications of the loop antenna used.

1. Set the AM rf signal generator frequency to 145 kHz, modulation to 400 Hz, 30%.
2. Turn TUNING knob of the set and tune in 145 kHz signal to obtain maximum VTVM reading.
3. Vary the AM rf signal generator attenuator to obtain 0.64 V (50 mW output) on the VTVM. Note VTVM reading in dB.
4. Turn the modulation off and note VTVM reading in dB.
5. The difference of VTVM readings obtained in steps 3 and 4 is the signal-to-noise ratio at this condition.
6. Adjust the AM rf signal generator attenuator until 6 dB signal-to-noise ratio is obtained keeping 0.64 V (50 mW output) varying VOLUME control. If the set is not operating normally, 50 mW output may not be obtained at 6 dB signal-to-noise ratio.
7. Read the amount of the signal generator attenuator and determine the maximum sensitivity.
8. LW maximum sensitivity is 316  $\mu$ V/m (50 dB/m).





**MEMO**

Lined area for writing on page 12.

**MEMO**


Lined area for writing on page 13.

SECTION 4  
DIAGRAMS


4-1. MOUNTING DIAGRAM

- Conductor Side -


Q1: 2SK42




Q2-6, D1: 2SC710




Q7-9: 2SC945



Q10, 11: 2SC1429




IC1: CX-075A






D2, 3: 1T281

D4-6: 1S1555




● DC RESISTANCE



TONE CONTROL /  
POWER SWITCH C.B.



VOLUME CONTROL  
C.B.

MAIN C.B.




Q	10	11	9	8	6	5		
IC						IC1		
D	VDR					3 2	5	6 4

BATTERY 4.5V (SIZE "C" x 3)




# ICF-545OL ICF-545OL

Q	10	11	9	8	6	5	7	4	2	3	1
IC	IC1										
D	VDR										
				3 <sub>2</sub>	5		6	4			



# ICF-545OL ICF-545OL

## 4-2. SCHEMATIC DIAGRAM



**Note:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  $p = \mu\text{F}$
- All resistors are in  $\Omega$ ,  $\frac{1}{2}W$ , unless otherwise noted.  $k = 1,000$   $M = 1,000 k$
- Coil resistances are out-of-circuit values.
- $\Delta$ : indicates internal components.
- Parts indicated by  $\blacksquare$  are mounted on the conductor side.
- C.B.: Circuit Board
- Transistor is used for D1 instead of diode.


- Voltages are DC with respect to ground unless otherwise noted. Readings taken under no-signal conditions with a VOM (20  $k\Omega/V$ ).
- ( ): FM { } : LW/MW  
no mark: common  
 $\blacksquare$  : B+
- Voltages between base and emitter are measured with 2.5 V range.
- Voltage variations may be noted due to normal production tolerances.

○ Switch Mode

Ref. No.	Switch	Position
S1-1-1-10	BAND SELECTOR	FM
S2	AFC	OFF
S3	POWER	OFF
S4	LIGHT	OFF
S5	TIMER	OFF

# ICF-545OL ICF-545OL

## SECTION 5 EXPLODED VIEW



**Note:**

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- (-) = slotted head

**SECTION 6  
ELECTRICAL PARTS LIST**

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
<b>CIRCUIT BOARDS</b>		
	1-504-390-00	VOLUME Control
	1-584-388-00	AFC Switch
	1-584-389-00	TONE Control/POWER Switch

**SEMICONDUCTORS**

**Transistors**

Q1	2SK42 (FET)
Q2~6	2SC710
Q7~9	2SC945
Q10,11	2SC1429

**IC**

IC1	CX-075A
-----	---------

**Diodes**

D1	2SC710
D2,3	1T261
D4~6	1S1555
VDR1	VD1123

**TRANSFORMERS**

CFA	1-404-005-00	IFT, ceramic filter
IFT A	1-403-960-00	AM IFT
IFT F1	1-403-872-00	FM IFT
IFT F2	1-403-959-00	FM DISCRI (primary)
IFT F3	1-403-953-00	FM DISCRI (secondary)
T1	1-423-159-00	Input
T2	1-427-316-00	Output

**COILS**

L2	1-401-455-00	FM Bandpass
----	--------------	-------------

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
L3	1-425-888-00	FM RF
L4	1-407-180-XX	Microinductor, 1.5 $\mu$ H
L5	1-405-568-00	FM OSC
L7	1-407-186-XX	Microinductor, 4.7 $\mu$ H
L8	1-407-157-XX	Microinductor, 10 $\mu$ H
L9, 10	1-401-636-00	Ferrite-rod Antenna, LW/MW
L11	1-405-520-00	MW OSC
L12	1-405-680-00	LW OSC
L13	1-407-169-XX	Microinductor, 100 $\mu$ H

**CAPACITORS**

All capacitors are in  $\mu$ F and ceramic type unless otherwise noted. (p =  $\mu$  $\mu$ F, elect = electrolytic) 50 or less working volts are omitted except for electrolytic type.

C2	1-102-937-11	4 p	
C4	1-102-934-11	1 p	
C5	1-102-953-11	18 p	
C6	1-102-074-11	0.001	
C7	1-102-936-11	3 p	
C8	1-102-934-11	1 p	
C9	1-107-091-11	180 p	silvered mica
C10	1-101-923-11	0.01	
C11	1-102-951-11	15 p	
C12	1-102-074-11	0.001	
C13	1-102-721-11	24 p	
C14	1-101-997-11	5 p	
C15	1-101-923-11	0.01	
C16	1-102-959-11	22 p	
C17	1-102-949-11	12 p	
C18	1-101-923-11	0.01	
C19	1-107-089-11	150 p	silvered mica
C20	1-103-714-11	360 p	styrol
C21	1-102-947-11	10 p	
C22, 23	1-101-923-11	0.01	
C24	1-102-074-11	0.001	
C25	1-102-074-11	0.001	

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	
C27	1-102-125-11	0.0047	
C28	1-101-923-11	0.01	
C29	1-102-973-11	100 p	
C30	1-102-949-11	12 p	
C31	1-101-890-11	75 p	
C32	1-101-923-11	0.01	
C33	1-106-082-12	0.01	mylar
C34	1-101-118-11	0.01	
C35, 36	1-101-923-11	0.01	
C37	1-102-121-11	0.0022	
C38	1-102-958-11	20 p	
C39, 40	1-101-923-11	0.01	
C41	1-121-736-11	1000	10 V elect
C42	1-121-402-11	33	10 V elect
C43	1-121-413-11	100	6.3 V elect
C44	1-121-658-11	2200	6.3 V elect
C45	1-121-651-11	10	16 V elect
C47	1-101-797-11	0.1	
C48	1-121-391-11	1	50 V elect
C49	1-106-082-12	0.01	mylar
C50	1-101-797-11	0.1	
C51	1-121-391-11	1	50 V elect
C52	1-121-420-11	220	10 V elect
C53, 54	1-121-424-11	470	6.3 V elect
C55, 56	1-121-402-11	33	10 V elect
C57	1-121-736-11	1000	10 V elect
C58	1-102-121-11	0.0022	
C59	1-107-092-11	200 p	silvered mica
C60~62	1-101-797-11	0.1	
C63, 64	1-101-118-11	0.01	
C65	1-108-276-12	0.0068	mylar
C66	1-102-973-11	100 p	
C67~69	1-101-923-11	0.01	
C70	1-102-121-11	0.0022	
C71	1-102-966-11	43 p	
C73	1-102-973-11	100 p	
C75	1-102-074-11	0.001	
C76	1-121-391-11	1	50 V elect
C77	1-101-797-11	0.1	
C78, 79	1-102-074-11	0.001	
C80	1-102-947-11	10 p	
C81	1-101-797-11	0.1	
C82	1-102-958-11	20 p	
CT1, 2	1-141-097-21	Trimmer	

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
CT3, 4	1-141-144-00	Trimmer
CT5, 6	1-141-097-31	Trimmer
VC1	151-196-00	Tuning

### RESISTORS

All resistors are in  $\Omega$ ,  $\frac{1}{4}$ W. Regular type  $\pm 5\%$  carbon and composition resistors are omitted. Check schematic diagram for resistance values. k = 1000, M = 1000k

R64	1-207-455-11	22	$\frac{1}{4}$ W wirewound
VR1	1-224-579-00	10 k (A), variable;	TREBLE
VR2	1-224-580-00	20 k (E), variable;	VOLUME
VR3	1-224-579-00	10 k (A), variable;	BASS

### SWITCHES

S1	1-516-071-00	Slide, BAND SELECTOR
S2	1-516-607-41	Toggle, AFC
S3	1-516-607-31	Toggle, POWER
S4		LIGHT (built in main circuit board)
S5	1-548-048-00	TIMER

### FILTERS

BF1	1-403-997-00	AM, ceramic
CF1	1-527-198-11	FM I-f, ceramic; 10.70 MHz (nd)
CF2	1-527-198-21	FM I-f, ceramic; 10.67 MHz (lue)
CF3	1-527-198-31	FM I-f, ceramic; 10.73 MHz (range)

### MISCELLANEOUS

CR1	1-231-202-00	Encapsulated Component, 6.8 k $\Omega$ + 6.8 k $\Omega$ + 220 pF + 20 pF
CR2	1-231-211-00	Encapsulated Component, 1 k $\Omega$ + 0.01 $\mu$ F + 0.01 $\mu$ F
J1~5	1-507-369-00	Jack, 5-unit (MPX OUT/rec out/ TIMER IN/EXT POWER N DC 4.5 V/earphone)
ME	1-520-133-00	TUNING METER
PL	1-518-169-XX	Lamp, pilot; 4.5 V/40 mA
SP	1-502-538-00	Speaker, 8 $\Omega$
TEL ANT	1-501-106-00	Antenna, telescopic













<u>Part No.</u>	<u>Description</u>
<b>HARDWARE</b>	
<b>SCREWS</b>	
All screws are Phillips (cross recess) type unless otherwise noted.	
7-621-259-65	P 2.6 x 10
7-682-146-01	P 3 x 5
7-685-146-11	P 3 x 8, self-tapping
7-685-533-21	B 2.6 x 6, self-tapping

<u>Part No.</u>	<u>Description</u>
<b>ACCESSORIES</b>	
X-3840-409-0	Strap, shoulder
1-504-034-12	Earphone, ME-20
3-995-724-11	Manual, instruction

<b>MISCELLANEOUS</b>	
7-623-107-11	Washer 2.6
7-624-109-01	Retaining Ring E-5
7-625-208-60	Nylon Rivet 2 x 6
7-625-209-20	Nylon Rivet 2 x 12
7-671-114-01	Steel Ball 4
7-684-035-00	Nut 5

*When ordering replacement parts, use PART NUMBERS listed in Parts List or shown in EXPLODED VIEW. Parts List reference numbers should not be used.*

<b>P</b> - Pan Head Screw .....		<b>SC</b> - Set Screw .....	
<b>PS</b> - Pan Head Screw with Spring Washer .....		<b>E</b> - Retaining Ring (E Washer) .....	
<b>K</b> - Flat Countersunk Head Screw .....		<b>W</b> - Washer	
<b>B</b> - Binding Head Screw .....		<b>SW</b> - Spring Washer	
<b>RK</b> - Oval Countersunk Head Screw .....		<b>LW</b> - Lock Washer	
<b>T</b> - Truss Head Screw .....		<b>N</b> - Nut	
<b>R</b> - Round Head Screw .....			
<b>F</b> - Flat Fillister Head Screw .....			

**- Example -**

P 3x10

Length in mm (L)

Diameter in mm (D)

Type of Head

