


ICF-6500L

AEP Model



FM/SW/MW/LW 6BAND RECEIVER

SPECIFICATIONS

Frequency range	FM 87.6-107 MHz SW ₁ 3.9-10 MHz (77-30 m) SW ₂ 11.7-20 MHz (25.6-15 m) SW ₃ 20-26.1 MHz (15-11.5 m) MW 530-1,605 kHz (566-187 m) LW 150-255 kHz (2,000-1,176 m)	Dimensions	Approx. 289 × 169 × 102 mm (w/h/d) (11½ × 6¾ × 4⅞ inches) incl. projecting parts and controls
Antennas	SW/FM: Telescopic antenna MW/LW: Built-in ferrite bar antenna	Weight	Approx. 1.85 kg (4 lb 1¼ oz) incl. batteries
Speaker	Approx. 10 cm (4 inches) dia.		
Power output	1,100 mW (at 10% harmonic distortion)		
Outputs	Earphone jack (minijack) for 8-ohm earphone or load impedance 10 kilohms or higher Recording output jack (minijack) output level 1 mV (-60 dB) output impedance 1 kilohm		
Power requirements	9 V dc, six batteries IEC designation R14 (size C) 12 V car battery with optional Sony DCC-120 car battery cord 24 V car battery with optional Sony DCC-240 car battery cord		
Battery life	Approx. 24 hours using Sony SUM-2 (NS) New Super batteries or Eveready No. 1235 Heavy Duty batteries		



SONY®

SERVICE MANUAL

Handling Precautions for MOS ICs

- A MOS IC (IC102) in this set should be replaced as a counter block.

Generally, the insulation resistance of the oxide layer in MOS IC structures is very high, and the oxide layer is very thin. Because of this, it is possible that the static voltages usually present on clothes and the human body will be enough to generate a potential difference across the insulator, high enough to cause a breakdown of the insulating layer.

The following precautions should be taken while handling these ICs.

(Particular care should be taken under conditions of low humidity.)

Precautions in Replacing MOS ICs

1. Store new ICs by inserting them into a urethane-polyester cushion (which is somewhat conductive), or wrapping it in aluminum foil, so that all the pins are at the same potential. (The ICs should be stored in that manner until mounted on the circuit board.)




Fig. A




Fig. B

2. Check the soldering iron for possible power-line leakage current. Make sure that there is no leakage path by connecting an ohmmeter to the tip of the soldering iron and the plug as shown in Fig. C. If there is a leakage path, use some other soldering iron.




Fig. C

3. Equalize any potential difference between the clothes, the tools in use, the work bench, the set being worked on, and the packaged IC by touching them all in succession with the hands or a conductive wire or tool.
4. The following are effective methods for handling ICs that remove the potential difference across the oxide layer.
 - Use a paper clip modified by soldering in a wire braid insert.




Fig. D

Make sure that there is no solder on the inside.




Fig. E




Fig. F

Make sure that all the pins are in contact with the wire braid (all the pins will then be at the same potential.).

- Take a short length of fine bare wire and wind it around the IC so that it shorts all the pins of the IC, while it is still in the urethane-polyester cushion or aluminum foil. This ensures that all the pins are at the same potential.




Fig. G

- When it is necessary to handle the IC with the fingers, do not touch any pin, and hold the IC at the ends of its plastic-package as shown in Fig. H.




Fig. H

5. Method of Mounting

Insert the IC while holding it with the modified clip, and solder all the pins with the clip still shorting the pins. (Similarly, solder all the pins while the bare shorting wire is still wound around them.). Remove the clip or the bare shorting wire only after all the pins have been soldered.

Precaution while Checking C-MOS ICs

The C-MOS ICs (Complementary MOS) are MOS ICs that have their output sections made up of N-channel and P-channel push-pull stages to increase their speed of operation. If the output terminal of these ICs comes into contact with B+ or B- voltage, then the FET which is ON at that time will either become shorted or open.

This is valid for all the output sections that are connected together by the interconnections. Even the circuits that are physically separated (and not on the same board) can be destroyed simultaneously.

Example:





Fig. I

LOCATION AND FUNCTION OF CONTROLS



Key marks on the front panel
 ■ for SW reception
 □ for MW and LW reception

① LIGHT button

While operating, depress the button to illuminate the frequency counter and TUNING meter.

② Telescopic antenna

Used for FM and SW reception.

③ POWER switch

Set to ON to turn on the power. After using, set to OFF.

④ AM SENS (AM sensitivity) switch

Used for SW, MW and LW reception.

⑤ BFO (beat frequency oscillator) switch

Used for SSB/CW reception.

⑥ Dial scale and pointer

⑦ Frequency counter

⑧ TUNING meter

⑨ TUNING knob

Turn to tune the frequency of the desired station, as marked on the dial scale so that the pointer of the TUNING meter swings to the right as far as possible. Pull the knob and turn for precise tuning.

⑩ Battery compartment (bottom)

⑪ Speaker

⑫ TONE control

Turn to MUSIC to enhance both low and high frequency signals and to NEWS to suppress them.

⑬ VOLUME control

Turn clockwise for more volume.

⑭ BAND selector switch

Choose the desired band; MW, LW, SW₁, SW₂, SW₃, or FM. The frequency range of the selected band will appear on the dial scale.

⑮ DC IN 9V jack

For operation on car battery.

⑯ (earphone) jack

For private listening with an earphone.


⑰ (recording output) jack

For recording radio programs with a tape recorder.

⑱ Strap loop

See the illustrations on the right column.

SECTION 1
BLOCK DIAGRAM





• SWITCH

Ref. No.	SWITCH	POSITION
S1	BAND	SW3
S2	LW/MW SELECT	MW
S3	FM/MW SELECT	FM
S4	BFO	OFF
S5	AM SENS	HIGH
S6	POWER	OFF
S7	LIGHT	OFF



SECTION 2 DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.




Meter Holder Ass'y and Counter Ass'y Removal

Perform in the order ③, ④ when meter only is removed.




• Cord Stringing for Band Selection
(See page 15.)

• Meter Holder Assembling
(See page 13.)




Main Board Removal



Lever Removal


- 1 Push shaft (B) in the direction of arrow 1
- 2 Remove lever by pushing both sides of lever in the direction of arrows 2 simultaneously.



• Dial Cord Stringing
(See page 16.)

• Switch Holder Installation
(See page 14.)


Chassis (B) Ass'y Removal




• Chassis (B) Assembling
(See pages 11, 12.)

CHASSIS (B) ASSEMBLING


1. Bearing (B) Installation




4. Shaft (B) Ass'y Installation




6. Gears (F, G) and Dial Drum Installation




2. Gear (A) Installation




3. Gear (B) Installation



5. Gears (C, D, E) Assembling and Installation






7. Adjustment






METER HOLDER ASSEMBLING

Note: Before installing ①, ② and ③, clean them with soft dry cloth.




SWITCH HOLDER ASSEMBLING



- After completing procedures ① and ② set main board.
- After completing the adjustments, set the band knob to MW and make sure that the following items are met.
 1. ⓑ is no clearance.
 2. The switch lever is not pushed.

BAND SELECT CORD STRINGING

1. Preparation




2 Tie cord as shown and apply lock paint there...



2. Stringing

- Perform in the numerical order given


5 Wind cord three turns from inner to outer sides of pulley.




1 Rotate band select shaft fully clockwise.

3. Dial Scale Setting

1 Set dial scale to SW1, and adjust dial scale so that dial scale is parallel with dial back plate.




2 Hook cord with screwdriver as illustrated.



DIAL CORD STRINGING

1. Preparation

①




② Tie cord to spring and apply lock paint there.



2. Stringing

- Perform in the numerical order given.
- Turn tuning shaft fully clockwise.




3. Pointer Setting


① Turn tuning knob fully counterclockwise and set dial pointer to specified position on dial scale.



pointer position



② Apply lock paint.



SECTION 3 ADJUSTMENTS

1. FM Adjustment




Note: Adjustment should be made in the order of FM, MW and SW.

Setting:


BAND FM
 VOLUME MAX
 BFO OFF

- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.
- When making FM adjustments only, make sure that SW frequency coverage adjustment is done.

Procedure:



FM IF ALIGNMENT 2
(10.7 MHz with no modulation)
Adjust for 0V reading on VOM ②.
T5



FREQUENCY COVERAGE ADJUSTMENT

Adjust for a maximum reading on VOM ①.

L9	87.35 MHz
CT1-2	107.5 MHz

FM rf signal generator

T1

Adjust for a maximum reading on VOM ①.

FM IF ALIGNMENT 1
(10.7 MHz with modulation)

L10	87.35 MHz
CT1-1	107.5 MHz

Adjust for a maximum reading on VOM ①.

TRACKING ADJUSTMENT

2. MW Adjustment



Note: This should be performed after FM adjustment.

Setting:

BAND MW
 AM SENS HIGH
 BFO OFF
 VOLUME MAX


- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.
- When making MW adjustments only, make sure that SW frequency coverage adjustment is done.

Procedure:



AM IF ALIGNMENT	
Adjust for a maximum reading on VOM.	
455 kHz	T3

MW FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VOM.	
520 kHz	1,680 kHz
L1	CT1-3



MW TRACKING ADJUSTMENT	
Adjust for a maximum reading on VOM.	
CT1-4	1,400 kHz
L5	620 kHz

3. LW Adjustment


Note: This should be performed after MW adjustment.

Setting:

BAND LW
 AM SENS HIGH
 BFO OFF
 VOLUME MAX


- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.
- When making LW adjustments only, make sure that SW frequency coverage adjustment is done.

Procedure:




30% amplitude modulation by 400 Hz signal

VOM (range: 0.5-5V ac)



LW FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VOM.	
265 kHz	145 kHz
CT-4	L26

LW TRACKING ADJUSTMENT	
Adjust for a maximum reading on VOM.	
250 kHz	CT-5
170 kHz	L25



SW Adjustment


Note: This should be performed after LW adjustment.

Setting:

BAND SW
 AM SENS HIGH
 BFO OFF
 VOLUME MAX

- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.
- Perform in the numerical order given.

Procedure:




1

SW3 IF ALIGNMENT
Adjust for a maximum reading.
10.7 MHz
T2

2

SW FREQUENCY COVERAGE ADJUSTMENT		
SW1	L2	3.8 MHz
	CT-1	10.35 MHz
SW2	L3	11.5 MHz
	CT-2	20.35 MHz
SW3	L4	19.85 MHz
	CT-3	26.25 MHz

FREQUENCY COVERAGE ADJUSTMENT
 CT-1 L2 CT-2 L3 CT-3 L4



AM RF SSG

3

L6
3.8 MHz
SW1 TRACKING ADJUSTMENT

4

L7
11.5 MHz
SW2 TRACKING ADJUSTMENT

5


L8
19.85 MHz
SW3 TRACKING ADJUSTMENT

5. BFO Adjustment

Setting:

BAND MW
VOLUME as low as possible



1. Tune in an off-the-air signal by turning tuning knob.
2. Set BFO switch to ON and adjust L13 so that no beat sound is heard.



4-1. MOUNTING DIAGRAM
- Conductor Side -

SECTION 4
DIAGRAMS

	A	B	C	D	E	F	G
Q							
IC	10	9 8 2	1	5 4 13 12 11	101 7 102 14	17 19 18 IC2 6 16	15
D	7			8 10 9	2 1 3 101 102 103 104 105 106	13, 14 11, 12 4	6 5




- Note:
- : parts extracted from the component side.
 - : parts extracted from the conductor side.
 - : part mounted on the conductor side.
 - : indicates side identified with part number.
 - : B + pattern

Semiconductor Lead Layouts

2SA1027R
2SA733-Q




1S1555
1S2139C
1T261
SD-115



2SC710-13
2SC710-14




KB-4419C




2SC1363
2SC1363-7
2SC1363-8




μ 54460L




2SC2839
2SC2839E
2SC536SP
2SC536SP-F




μ PC-1213C




2SK161-0
2SK161
2SK161-Y




2SC2786-L




2SK241-Y




MSM5527RS



4-2. MOUNTING DIAGRAM - Component Side -




ICF-6500L ICF-6500L




Note:

- —: parts extracted from the component side.
- —: parts extracted from the conductor side.
- ■: part mounted on the conductor side.
- □: indicates side identified with part number.
- —: B + pattern
- —: signal path

4-3. SCHEMATIC DIAGRAM



Note:



Note:

- All capacitors are in μF unless otherwise noted. $\text{pF} : \mu\text{F}$ 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in ohms, $\frac{1}{4}$ W unless otherwise noted. $\text{k}\Omega : 1000 \Omega$, $\text{M}\Omega : 1000 \text{k}\Omega$
- Δ : internal component.
- \square : panel designation.
- --- : B+ bus.
- Voltages are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- Readings are taken under no-signal (detuned) conditions with a VOM (20 $\text{k}\Omega/\text{V}$).

() : MW < > : SW no mark: FM
 << >> : LW

• Switch

Ref. No.	Switch	Position
S1	BAND	SW3
S2	MW-LW CHANGE	MW
S3	FM-MW CHANGE	FM
S4	BFO	OFF
S5	AM SENS	HIGH
S6	POWER	OFF
S7	LIGHT	OFF

115941

SECTION 5
EXPLODED VIEWS AND PARTS LIST

