


# WM-A26/B26

## SERVICE MANUAL



*US Model*  
WM-A26

*UK Model*  
*E Model*

*West Germany Model*  
WM-B26

Model Name	Using Similar Mechanism	New Mechanism
Tape Transport Mechanism Type		MT-WMA26-19

### Specifications

Power requirements 3 V DC Batteries R6 (AA) × 2  
BP-700 rechargeable battery  
External DC 3 V power sources

Battery life (Approximate hours)

Sony Alkaline AM3 (N)	8 hrs.
Rechargeable BP-700	2 hrs.

Accessories supplied Stereo headphones (open-air type, 1) Beltclip (1)  
Battery tube (1)

### Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

### Flexible Circuit Board Repairing


- Keep the temperature of the soldering iron around 270°C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.



MICROFILM

CASSETTE PLAYER  
**SONY**®


## SECTION 1 GENERAL



## SECTION 2 DISASSEMBLY


### 2-1. DISASSEMBLY

- Note:**
- Follow the disassembly procedure in the numerical order given.
  - It is recommended to prepare a plastic wedge shown below for rear cabinet removal. (Using a precision screwdriver for a plastic wedge may flaw the cabinet face.)




### CASSETTE HOLDER

- ❶ Remove the battery lid.
- ❷ Hold the front cabinet firmly.




- ❸ Insert a precision screwdriver (1.4mm flat-blade) vertically into portion 5 to release the hinge plate.

- ❹ Remove bottom side of the cassette holder slowly.



### MECHANISM DECK


### MAIN BOARD




{ When installing, set the FWD/REV }  
switch to FWD

**REAR CABINET**

- ② Insert a plastic wedge into the gap to keep the gap wide. (Portion ⑤ is the most proper portion for wedge.)




- ① Insert the screwdriver into the slit at claw A, and release the claw.



- ③ Release all claws ② to ④ in the alphabetical order.

- ④ Remove the rear cabinet.


**Location and Shape of Claws.**



Ⓐ to Ⓔ: claws

2 - 2. ASSEMBLY

CASSETTE HOLDER



SECTION 3  
ADJUSTMENTS

3 - 1. MECHANICAL ADJUSTMENTS

PRECAUTION

- Clean the following parts with a denatured alcohol moistened swab:
 

playback head	pinch roller
capstan	rubber belts
- Demagnetize the playback head with a head demagnetizer.
- Do not use a magnetized screwdriver for the adjustments.
- After the adjustments, apply suitable locking compound to the parts adjusted.
- The adjustments should be performed with the rated power supply voltage (2.5V) unless otherwise noted.

Torque Measurement

Mode	Torque meter	Meter reading
FWD	CQ-102C	20-35 g·cm (0.28-0.48 oz·inch)
FWD Back Tension		less than 3 g·cm (less than 0.04 oz·inch)
REV	CQ-102RB	20-35 g·cm (0.28-0.48 oz·inch)
REV Back Tension		less than 3 g·cm (less than 0.04 oz·inch)
FF, REW	CQ-201B	more than 60 g·cm (more than 0.83 oz·inch)

Tape Tension Measurement

Mode	Tension meter	Meter reading
FWD	CQ-403A	more than 65 g (more than 2.3 oz)
REV	CQ-403R	

### 3-2. ELECTRICAL ADJUSTMENTS

#### PRECAUTION

- Supplied voltage : 2.5V
- Switch and control position  
TAPE switch : NORM

VOLUME CONTROL : maximum

#### TEST TAPE

Type	Signal	Used for
WS-48A	3 kHz, 0 dB	Tape Speed Adjustment
P-4-A100	10 kHz, -10 dB	Playback Head Azimuth check

#### PLAYBACK HEAD AZIMUTH CHECK


- Perform this check both in FWD and REV mode.

Note: This set is not featured the head azimuth adjustment.  
When replacing the head, check the both L-ch and R-ch output levels and also those phases.

#### Procedure:



##### 1. Level Check

Mode: playback



##### 2. Phase Check


Mode: playback



#### TAPE SPEED ADJUSTMENT

#### Procedure:

Mode: playback




#### Specification:

speed checker	digital frequency counter
±1%	2,970 - 3,030 Hz


Frequency difference between the beginning and the end of the tape should be within ±2.5% (±75 Hz).

Adjustment Location: main board






SECTION 4  
DIAGRAMS

4-1. SCHEMATIC DIAGRAM



- Note:**
- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  $\text{pF}$ :  $\mu\text{pF}$  50WV or less are not indicated except for electrolytics and tantalums.
  - All resistors are in  $\Omega$  and  $\frac{1}{8}$  W or less unless otherwise specified.
  - **B+**: B+ Line
  - : adjustment for repair.
  - Total current is measured with no cassette installed.
  - Power voltage is dc 3V and fed with regulated dc power supply from external power voltage jack.
  - Voltage and waveforms are dc with respect to ground in playback mode
  - Voltages are taken with a VOM (input impedance 10M  $\Omega$ ) Voltage variations may be noted due to normal production tolerances.
  - Signal path.
  - $\curvearrowright$ : PB







Semiconductor Location

Ref. No.	Location
IC301	F-4

Semiconductor Lead Layouts



DRY BATTERY  
SIZE "AA"  
(REC DESIGNATION R6)  
2PCS, 3V



Note:  
 • ○ — : parts extracted from the component side.  
 • ■ : parts mounted on the conductor side.



### SECTION 5 EXPLODED VIEWS


**NOTE:**

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.


- Color Indication of Appearance Parts  
Example:  
(RED) ... KNOB, BALANCE (WHITE)
- ↑ Cabinet's Color                                  ↑ Parts Color

5-1.



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
1	X-3346-720-1	CABINET (REAR) (TC) ASSY		7	3-351-523-01	SPRING, TORSION	
2	3-351-535-01	LID, BATTERY CASE		8	X-3346-737-1	CABINET (FRONT) (TC) ASSY	
3	3-351-739-11	SPRING		9	3-351-529-01	BUTTON (S)	
4	3-351-531-01	TERMINAL BOARD (M), BATTERY		10	3-351-528-01	BUTTON (FR)	
5	3-351-530-01	TERMINAL BOARD (P), BATTERY		11	3-351-527-01	BUTTON (P)	
6	X-3346-733-1	HOLDER (TC-A) ASSY, CASSETTE		901	A-3015-738-A	PC BOARD ASSY, MAIN	

5-2. MECHANISM DECK (MT-WMA26-19)



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remark
301	X-3336-795-1	CHASSIS SUB ASSY		307	3-351-733-01	LEVER, PLAY	
302	3-351-597-01	GEAR (R)		308	3-351-599-11	BELT	
303	3-351-715-01	SPRING, COMPRESSION		309	7-627-852-38	SCREW, PRECISION +P 1.7X1.8 TYPE 3	
304	3-351-710-01	SPRING (PREVENTION), TORSTON		310	*3-351-792-01	PAPER, SHIELD	
305	3-352-737-01	PINCH ROLLER		HP901	1-543-596-11	HEAD, MAGNETIC (PLAYBACK)	
306	3-351-732-01	PINCH LEVER		M901	1-541-648-11	MOTOR, DC	

# SECTION 6 ELECTRICAL PARTS LIST

**NOTE:**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

**CAPACITORS:**

MF:  $\mu$ F, PF:  $\mu$  $\mu$ F.

**RESISTORS**

- All resistors are in ohms.
- F: nonflammable

**COILS**

- MMH: mH, UH:  $\mu$ H

**SEMICONDUCTORS**

In each case, U:  $\mu$ , for example:

UA....:  $\mu$ A...., UPA....:  $\mu$ PA....,  
UPC....:  $\mu$ PC, UPD....:  $\mu$ PD....

Ref.No.	Part No.	Description			
901	A-3015-738-A	PC BOARD ASSY, MAIN			
C101	1-163-133-00	CERAMIC CHIP 470PF	10%	50V	
C102	1-163-133-00	CERAMIC CHIP 470PF	10%	50V	
C103	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C104	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C105	1-124-432-00	ELECT 47MF	20%	4V	
C106	1-163-023-00	CERAMIC CHIP 0.015MF	5%	50V	
C107	1-162-638-11	CERAMIC CHIP 1MF		16V	
C116	1-124-434-00	ELECT 220MF	20%	4V	
C117	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C118	1-163-009-11	CERAMIC CHIP 0.001MF	10%	50V	
C201	1-163-133-00	CERAMIC CHIP 470PF	10%	50V	
C202	1-163-133-00	CERAMIC CHIP 470PF	10%	50V	
C203	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C204	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C205	1-124-432-00	ELECT 47MF	20%	4V	
C206	1-163-023-00	CERAMIC CHIP 0.015MF	5%	50V	
C207	1-162-638-11	CERAMIC CHIP 1MF		16V	
C216	1-124-434-00	ELECT 220MF	20%	4V	
C217	1-163-125-00	CERAMIC CHIP 220PF	10%	50V	
C218	1-163-009-11	CERAMIC CHIP 0.001MF	10%	50V	
C302	1-124-434-00	ELECT 220MF	20%	4V	
C303	1-163-205-00	CERAMIC CHIP 0.001MF	10%	50V	
C304	1-162-638-11	CERAMIC CHIP 1MF		16V	
C305	1-124-434-00	ELECT 220MF	20%	4V	
C313	1-124-434-00	ELECT 220MF	20%	4V	
C601	1-124-434-00	ELECT 220MF	20%	4V	
CH301	*1-565-370-11	HOUSING, CONNECTOR 5P			
CP601	1-466-100-11	SERVO UNIT			
HP901	1-543-596-11	HEAD, MAGNETIC (PLAYBACK)			
IC301	8-759-820-66	IC LA4580M			
J301	1-565-287-11	JACK (PHONES)			
J302	1-565-286-11	JACK, OUTER POWER (DC IN 3V)			
JR1	1-216-295-00	METAL GLAZE	0	5%	1/10W
JR2	1-216-295-00	METAL GLAZE	0	5%	1/10W
JR4	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR6	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR7	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR8	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR9	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR10	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR11	1-216-296-00	METAL GLAZE	0	5%	1/8W

Ref.No.	Part No.	Description			
JR12	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR21	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR22	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR23	1-216-296-00	METAL GLAZE	0	5%	1/8W
M901	1-541-648-11	MOTOR, DC			
R103	1-216-034-00	METAL GLAZE	240	5%	1/10W
R104	1-216-105-00	METAL GLAZE	220K	5%	1/10W
R105	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
R106	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R107	1-216-025-00	METAL GLAZE	100	5%	1/10W
R203	1-216-034-00	METAL GLAZE	240	5%	1/10W
R204	1-216-105-00	METAL GLAZE	220K	5%	1/10W
R205	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
R206	1-216-075-00	METAL GLAZE	12K	5%	1/10W
R207	1-216-025-00	METAL GLAZE	100	5%	1/10W
R303	1-216-113-00	METAL GLAZE	470K	5%	1/10W
RV301	1-238-490-11	RES, VAR, CARBON 20K/20K (VOLUME)			
RV601	1-238-237-11	RES, ADJ, CERMET 470 (TAPE SPEED)			
S301	1-571-478-11	SWITCH, SLIDE (TAPE)			
S310	1-571-859-22	SWITCH, LEAF (TC POWER)			
S311	1-571-859-11	SWITCH, LEAF (DIR)			

**ACCESSORY & PACKING MATERIAL**

*3-342-930-11	STOPPER
3-346-518-01	CLIP, BELT
3-351-508-01	TUBE, PROTECTION
*3-351-548-01	(A26)...CUSHION (UPPER)
*3-351-552-01	(B26)...CUSHION (UPPER)
*3-351-558-01	(B26)...CUSHION (LOWER)
*3-351-571-01	(A26)...CUSHION (LOWER)
*3-351-789-01	(B26:UK, West Germany)...INDIVIDUAL CARTON
*3-351-791-01	(B26:E).....INDIVIDUAL CARTON
3-750-069-21	(A26).....MANUAL, INSTRUCTION
3-750-070-11	(B26:E,UK).....MANUAL, INSTRUCTION
3-750-070-41	(B26:West Germany)...MANUAL, INSTRUCTION
8-952-350-90	(B26:E).....HEADPHONE MDR-E454 SET
8-952-447-90	(A26, B26:UK, West Germany).....HEADPHONE MDR-006L SET