

Resistors

Rm1	39kΩ	F3
Rm2	6.8kΩ	F3
Rm3	1kΩ	F3
Rk1	680Ω	F3
Rk2	12kΩ	F3
Rk3	15kΩ	F3
Rk4	15kΩ	F3
Rk5	100Ω	F3
Rk6	330Ω	F3
Rk7	4.7kΩ	**
Rk8	820Ω	**
Rk9	47kΩ	**
Rk10	100Ω	**
Rk11	100Ω	**
Rk12	270Ω	**
Rk13	18kΩ	**
Ra1	6.8kΩ	**
Ra2	180Ω	**
Ra3	12kΩ	**
Ra4	10kΩ	**
Ra5	10kΩ	**
Ra6	10Ω	**
Ra7	1kΩ	**
Ra8	820Ω	**
Ra9	27Ω	**
Ra10	VA1034	**
Ra11	500Ω	D2
Ra12	430Ω	D2
Ra13	1Ω	D2
Ra14	1Ω	D2
Ra15	390Ω	C2
R1	20kΩ	H4

Capacitors

Cm1	125pF	F3
Cm2	118pF	F3
Cm3	69pF	F3
Cm5	0.047μF	F3
Cm6	0.02μF	F3
Cm7	466pF	F3
Cm8	520pF	F3
Cm9	69pF	E3
Cm10	118pF	E3
Tm1	30pF	E3
Tm2	30pF	E3
Tm3	50pF	E3
Ck1	0.047μF	**
Ck2	0.047μF	**
Ck3	250pF	**
Ck4	2.7pF	**
Ck5	250pF	**
Ck6	25μF	**
Ck7	0.47μF	**
Ck8	250pF	**
Ck9	2,200pF	**
Ck10	4,700pF	**
Ck11	0.22μF	**
Ca1	160μF	C2
Ca2	0.22μF	C2
Ca3	50μF	C2
Ca4	320μF	C2
Ca5	160μF	C2
Ca6	1,800pF	D2
Ca7	200μF	D2
Ca8	320μF	D2
C1	0.022μF	D2
VC1, VC2	—	G4
TC1	140pF	G4

Transistor Table

Transistor	Emitter (V)	Base (V)	Collector (V)
TXm1	AF117	0.95	7.5
TXk1	AF117	1.6	—
TXk2	OC70	—	4.0
TXa1	AC157	4.3	0.35
TXa2	AC113	0.25	—
TXa3	AC154	5.0†	9.0
TXa4	AC157	5.0†	0

† Measured at the junction of Ra13 and Ra14
Quiescent current 19mA.

TRANSISTOR ANALYSIS

Transistor voltages given in the table below, were taken from information supplied by the manufacturers. They were measured on a 20,000Ω/V meter and are negative with respect to battery positive.

CIRCUIT ALIGNMENT

Equipment Required.—An a.m. signal generator (output impedance 10Ω) capable of being modulated 30 per cent at 1kc/s; an audio output meter with an impedance of 8Ω; a screened test coil made up with 85 turns of enamel covered wire, wound on a 2in diameter former; a dummy aerial constructed as illustrated overleaf; 0.1μF and 18pF capacitors; an oscilloscope; an a.f. signal generator and a 100kΩ resistor.

Before starting the alignment procedure it is advisable to check the output balance as described in the following paragraph.

Output Balance Adjustment.—To check the balance of output transistors TXa3/TXa4, first ensure that the battery is in good condition and provides a nominal 9V on load. Connect the output meter via a miniature jack plug to the earphone socket (this disconnects the loudspeaker), and the oscilloscope across the input terminals of the output meter. Feed in a 1kc/s sine wave via the 100kΩ resistor to the top of the volume control R1 (the tape socket is a

convenient point), turn volume control to maximum and adjust the signal generator attenuator for a measured 700mW as indicated on the output meter. Adjust Ra4 in conjunction with the signal generator attenuator for equal clipping of the displayed waveform.

Alternatively an Avo model 8 set to the 10V d.c. range may be connected between the junction of Ra13/Ra14 and chassis (positive to chassis). Adjust Ra4 for a meter reading of 5V.

Remove test equipment, turn volume control to minimum and set Ra11 fully anti-clockwise. Connect a milliammeter in series with the negative power supply lead, in order to measure the quiescent current. Adjust Ra11 to increase the initial quiescent current by 4mA. The final quiescent current should be between 16mA and 19mA.

Alignment Procedure.—All r.f. and i.f. tuning adjustments are to be made with an a.m. signal modulated to a depth of 30 per cent at 1kc/s. The signal input should be progressively attenuated with increasing receiver sensitivity in order to maintain an output power of approximately 50mW as indicated on the output meter, with the volume control at maximum.

- 1.—Switch receiver to m.w.2 and rotate tuning gang to maximum capacitance. Connect output meter via a miniature jack plug to the earphone socket and connect the signal generator output via the 0.1μF capacitor to the base of the mixer/oscillator TXm1 (common pole of S3 is a convenient point).
- 2.—Feed in a 470kc/s a.m. signal and adjust Lk3, Lk2 and Lk1 for maximum output, repeating the adjustments until no further improvement is obtained. Disconnect signal generator.
- 3.—Ensure car press-button is released, connect the signal generator to the test coil and position the coil co-axially with the ferrite rod 6in from L1.
- 4.—Switch receiver to m.w.1, turn tuning gang to maximum capacitance and check that the cursor is in line with the end of the scale window. Feed in a 540kc/s a.m. signal and adjust Lm4 for maximum output.
- 5.—Switch receiver to m.w.2, turn tuning gang to minimum capacitance. Feed in a 1,620kc/s a.m. signal and adjust Tm3 for maximum output.
- 6.—Repeat operations 4 and 5 for optimum results.
- 7.—Switch receiver to m.w.1 and tune to 500m calibration mark. Feed in a 600kc/s a.m. signal and adjust L1 on the ferrite rod for maximum output.
- 8.—Switch receiver to m.w.2 and tune to 200m calibration mark. Feed in a 1,500kc/s a.m. signal and adjust Tm1 for maximum output.
- 9.—Repeat operations 7 and 8 for optimum results.
- 10.—Switch receiver to l.w., feed in a 225kc/s a.m. signal and tune receiver to this signal. Adjust L2 on ferrite rod for maximum output.
- 11.—Depress car press-button, set Tc1 to maximum capacitance (screw up tight but not excessively), and switch receiver to l.w. Feed in a 225kc/s a.m. signal via the 18pF capacitor and car aerial socket. Adjust Lm1 for maximum output.
- 12.—Remove 18pF capacitor and connect the signal to the car aerial socket via the dummy aerial.
- 13.—Switch receiver to m.w.1, feed in a 600kc/s a.m. signal, and tune receiver to this signal. Adjust Lm2 for maximum output.
- 14.—Switch receiver to m.w.2, feed in a 1,500kc/s a.m. signal and tune receiver to this signal. Adjust Tm2 for maximum output.
- 15.—Repeat operations 13 and 14 for optimum results.


Coils*

Lm1	11.6Ω	F3
Lm2	2.8Ω	F3
Lm3	—	F3
Lm4	1.8Ω	F3
Lm5	—	F3
Lk1	5.5Ω	**
Lk2	5.5Ω	**
Lk3	3.7Ω	**
Lk4	—	**
L1	1.8Ω	G4
L2	7.8Ω	H4
L3	8Ω	H4


Miscellaneous

S1-S5, S7-S9	—	E3
S11-S14	—	E3
S6, S10, S15, S16	—	H4
Dk1	CG64H	**

* Approximate d.c. resistance in ohms.
** Wired on type RMK10 panel (see Service Sheet 1841).



RGD - RR222



Dummy aerial as referred to in circuit alignment.