BAND	SIGNAL GENERATOR Frequency Setting	SIGNAL GENERATOR Dummy Antenna	Connection to Radio	Dial Setting	Trimmers Adjusted (in Order Shown)
455 Kc. I. F.	455 Kc.	.1 MFD.	Connect to Grid of 1A7	Rotor full open (Plates out of mesh)	Input and Output Trimmers on Top of I. F. cans
BROAD-CAST BAND	1600 Kc.	.1 MFD.	Connect to Grid of 1A7	Rotor full open (Plates out of mesh)	Osc. Trimmer on gang (See chassis view)
	1400 Kc.	200 MMF.	Connect to Antenna Clip	Set dial at 1400 Kc.	Ant. Trimmer on gang (See chassis view)





WARDS

MODEL 14BR-684A



CONDENSERS

C20	.004 x 600 V. Tubular Condenser
C2	.2 x 400 V. Tubular Condenser
C4, C6	.01 x 120 V. Tubular Condenser
C1	.05 x 120 V. Tubular Condenser
C5	.1 x 200 V. Tubular Condenser
C12	.006 x 120 V. Tubular Condenser
C7, C10, C13	.25 x 200 V. Tubular Condenser
C15, C14	.01 x 200 V.; .0001 x 200 V. Dual Tubular Condenser
C21	.1 x 200 V. Tubular Condenser
C16, C17, C18, C19	Electrolytic Filter Condenser 20 Mfd. x 50 V.; 40 Mfd. x 150 V.; 40 Mfd. x 150 V.; 200 Mfd. x 10 V. 50-60 Cycles
C8	.0005 Mica Type Condenser—20%
C3	.0001 Mica Type Condenser—20%
C9	.02 x 400 Volt Tubular Condenser

RESISTORS

R20	1 Megohm—⅓ Watt Resistor—20%
R13, R21	3 Megohm—⅓ Watt Resistor—20%
R7, R9, R17	5 Megohm—⅓ Watt Resistor—25%
R4, R15	20 Ohm—⅓ Watt Resistor—10%
R16	2500 Ohm—⅓ Watt Resistor—10%
R11	2M Ohm—⅓ Watt Resistor—10%
R10	15 Ohm—⅓ Watt Resistor—10%
R8	5M Ohm—⅓ Watt Resistor—20%
R3, R6	3M Ohm—⅓ Watt Resistor—20%
R22	700 Ohm—⅓ Watt Resistor—10%
R2	200M Ohm—⅓ Watt Resistor—20%
R5	65M Ohm—⅓ Watt Resistor—10%
R1	1M Ohm—⅓ Watt Resistor—20%
R12	47M Ohm—⅓ Watt Resistor—20%
R18	545 Ohm—14 Watt W.W. Resistor—5%
R19	1975 Ohm—6 Watt W.W. Resistor—5%
R23	350 Ohm—⅓ Watt Resistor—10%