



Resistors

R1	5.6kΩ	B1	R21	1.8kΩ	C2
R2	30kΩ	B2	RV1	5kΩ	A1
R3	1.2kΩ	A2	Capacitors		
R4	75kΩ	B2	C1	100μF	B1
R5	500Ω	B1	C2	40pF	B1
R6	4kΩ	A2	C3	50pF	B1
R7	24kΩ	B2	C4	—	A1
R8	4.7kΩ	B2	C5	—	A2
R9	4.7kΩ	B2	C6	0.01μF	B1
R10	1kΩ	B1	C7	5pF	A1
R11	1.5kΩ	B2	C8	0.01μF	A1
R12	2kΩ	C2	C9	15pF	A1
R13	680Ω	C1	C10	—	A2
R14	30kΩ	C1	C11	—	A2
R15	500Ω	C2	C12	50pF	A1
R16	100Ω	C2	C13	95pF	B1
R17	170kΩ	C1	C14	—	B2
R18	1.8kΩ	C2	C15	30μF	B2
R19	100Ω	C2	C16	0.04μF	B1
R20	100Ω	C2	C17	6pF	B2

C18	0.02μF	B2	L4	—	A2
C19	—	B2	L5	8Ω	C2
C20	0.02μF	B2	T1	—	B2
C21	0.04μF	B1	T2	—	B2
C22	9pF	B2	T3	—	B2
C23	—	B2	T4	—	C2
C24	0.02μF	B2	Miscellaneous		
C25	0.02μF	B2	D1	1S426	A2
C26	5μF	C1	S1-S10	—	B1
C27	30μF	C2	S11	—	A1
C28	5,000pF	C2			
C29	120pF	C1			
C30	100μF	C2			
C31	100μF	C2			
C32*	5pF	B1			

Coils and transformers

L1†	—	B1
L2	—	A1
L3	—	C1

* In later versions of models 1369 and PT302 C32 is 12pF.
† Not fitted in models 1371 and PT302.

Transistor table

Transistor	Emitter (V)	Base (V)	Collector (V)
TR1	2SA201A	0.82	0.75
TR2	2SA202D	0.13	0.28
TR3	2SA198P	0.65	0.83
TR4	TG48	—	—
TR5	2SB270	1.1	1.25
TR6	2SB270	1.66	1.85
TR7	2SB187	2.96	3.1
TR8	2SB187	0	0.15

Quiescent current 8mA (approximately)

Transistor analysis

Transistor voltages quoted in the table overleaf were obtained from information supplied by the manufacturers. They were measured under quiescent conditions with a model 8 Avometer and are all negative with respect to the positive line.

Circuit alignment

Equipment required. — An r.f. signal generator amplitude modulated 30 per cent at 1kc/s; two 0.1μF capacitors and an r.f. coupling loop.

Preset volume control to maximum and check condition of batteries in receiver. In order to avoid alignment error due to a.g.c. action, attenuate input signal so that the audio output is maintained at a level that just allows for a recognizable increase in gain.

Note: In the event of any adjustment being made to the m.w. circuits, l.w. and m.b. circuits must be realigned.

1. — Isolate the signal generator output by connecting a 0.1μF capacitor in each lead; switch receiver to m.w. and rotate tuning gang to maximum capacitance.

2. — Feed in a 470kc/s a.m. signal to the junction S4-S6/C6, and adjust T3, T2 and T1 for maximum output.

3. — Transfer signal generator output to the r.f. coupling loop and loosely couple loop to the ferrite rod aerial assembly, tune receiver to 500m. and feed in a 600kc/s a.m. signal. Adjust L4 and the position of L2 on ferrite rod for maximum output.

4. — Tune receiver to 200m. and feed in a 1,500kc/s a.m. signal. Adjust C10 and C4 for maximum output.

5. — Repeat operations 3 and 4 for optimum calibration and output.

6. — Switch receiver to l.w.; tune to 1,500m. and feed in a 200kc/s a.m. signal. Adjust C12 and the position of L3 on ferrite rod for maximum output.

If aligning a receiver with an M.B. bandwidth 185-225m. proceed to operation 7. For receivers with an extended bandwidth proceed to operation 8.

7. — Switch receiver to m.b.; tune to 216m. and feed in a 1,389kc/s a.m. signal. Adjust C9 and C3 for maximum output.

8. — Switch receiver to m.b.; tune to 247m. and feed in a 1,215kc/s a.m. signal. Adjust C9 and C3 for maximum output.

9. — Seal position of L2 and L3 on ferrite rod with polystyrene dope.

